

# Applications Manual for TUNS50/100



Rev. 1.4E 2019/7/3


## Contents

				Page	
1. Pin Assignment				A-1	
2. Conne	2. Connection for Standard Use				
2.1	Connection for standard use			A-2	
2.2	Input fuse	:	F11	A-3	
2.3	Input capacitor	:	C11	A-3	
2.4	Y capacitors and noise filters	:	CY,CX,L1	A-4	
2.5	Output capacitors	:	Co,C40	A-4	
2.6	Smoothing capacitor for boost voltage	:	Cbc	A-5	
2.7	Capacitor for boost voltage	:	C20	A-5	
2.8	Inrush current limiting thermistor	:	TH11	A-6	
3. Derati	ing			A-7	
3.1	Input voltage derating			A-7	
3.2	Output current derating			A-7	
4. Opera	tion under low temperature conditions	5		A-8	
4.1	Outline of low temperature operation			A-8	
4.2	4.2 Improvement of unstable operation			A-9	
4.3	Relationship between unstable operatio	n a	nd input voltage	A-9	
5. Holdup time				A-10	
6. Appendix				A-11	
7. Notes for external circuit design				A-12	



## 1 Pin Assignment


Fig.1.1 Pin configuration (bottom view) **•**TUNS50



●TUNS100

6

Ø



_					
Table 1.1 Pin configuration	No.		Pin	Function	
and function	TUNS50	TUNS100	Connection	Function	
	1	1	AC1	AC Input	
	2	2	AC2		
	3	3	+BC	+BC output	
	4	4	-BC	-BC output	
	5	5	+VOUT	+DC output	
	Ø	9	-VOUT	-DC output	
	-	8	-S	Remote sensing (-)	
	-	6	+S	Remote sensing (+)	

TRM


Adjustment of output voltage



## 2. Connection for Standard Use

#### 2.1 Connection for standard use

To use the TU series, external parts should be connected as shown in Fig. 2.1.The TU series should be conduction-cooled. Use a heatsink or fan to dissipate heat.



•Parts name are shown in Table 2.1 as reference.

• External parts should be changed according to the ambient temperature, and input and output conditions.

For details, refer to the selection method of individual parts.


## 2.2 Input fuse: F11

■ No protective fuse is preinstalled on the input side. To protect the unit, install a slow-blow type fuse shown in Table 2.2 in the input circuit.

Table 2.2	Model	TUNS50	TUNS100
Recommended	Rated current	2A	3.15A
fuse			

## 2.3 Input capacitor: C11

- Connect a film capacitor of 1 uF or higher as input capacitor C11.
- $\blacksquare$  Use a capacitor with a rated voltage of AC250V which complies with the safety standards.
- $\blacksquare$  If C11 is not connected, the power supply or external components may be damaged.
- Ripple current values flowing into C11 as listed in Table 2.1 are shown in Fig. 2.2.
- The frequency of the ripple current is 80 kHz to 600 kHz.
- $\blacksquare$  When selecting a capacitor, check the maximum allowable ripple current.
- The ripple current changes with PCB patterns, external parts, ambient temperature, etc. Check the actual ripple current value flowing through C11.





## 2.4 Y Capacitors and noise filters: CY, CX, L1

- The TU series have no internal noise filter. Connect external noise filters and capacitors (CY) to reduce conduction noise and stabilize the operation of the power supply.
- Noise filters should be properly designed when the unit must conform to the EMI/EMS standards or when surge voltage may be applied to the unit.
- Install the primary Y capacitor (CY1) as close as possible to the input pins (within 50 mm from the pins).

A capacitance of 470 pF or more is required.

- When the total capacitance of CYs exceeds 8,800 pF, input-output withstanding voltage may be dropped. In this case, either reduce the capacitance of Y capacitors or install a grounding capacitor between output and FG.
- Use capacitors with a rated voltage of AC250V which comply with the safety standards as CY.


#### 2.5 Output capacitors: Co, C40

- Install an external capacitor, Co, between +VOUT and -VOUT pins for stable operation of the power supply. Recommended capacitance of Co is shown in Table 2.3.
- Use low impedance electrolytic capacitors with excellent temperature characteristics.
- When used at ambient temperatures below 0 °C, the output ripple voltage increases due to the characteristics of equivalent series resistance (ESR). In this case, connect three capacitors, Co, of recommended capacitance in parallel connection.
- Specifications, output ripple and ripple noise as evaluation data values are measured according to Fig. 2.3.

Table 2.3Output VoltageRecommended5Vcapacitance12VCo24V

Output Voltage	TUNS50	TUNS100
$5\mathrm{V}$	2,200uF	2,200uF
12V	$470 \mathrm{uF}$	470uF
24V	$220 \mathrm{uF}$	220uF

Fig. 2.3 Measuring environment





## 2.6 Smoothing capacitor for boost voltage: Cbc

- To smooth boost voltage, connect Cbc across +BC and -BC. Recommended capacitance of Cbc is shown in Table 2.4.
- Install a capacitor Cbc whose rated voltage is DC420 V or higher within the allowable capacitance.
- When operated below 0°C, operation may become unstable as boost ripple voltage increases due to ESR characteristics. Choose a capacitor which has higher capacitance than recommended.

Select a capacitor so that the ripple voltage of the boost voltage is 30 Vp-p or below.


- If the ripple voltage of the boost voltage increases, the ripple current rating of the smoothing capacitor may be exceeded. Check the maximum allowable ripple current of the capacitor.
- The ripple current changes with PCB patterns, external parts, ambient temperature, etc. Check the actual ripple current value flowing through Cbc.

Table 2.4 Recommended capacitance Cbc

	Model	Recommended capacitance	Allowable capacitance range
-	TUNS50	82uF	$47 \mathrm{uF} \sim 150 \mathrm{uF}$
	TUNS100	120uF	$68\mathrm{uF}\sim220\mathrm{uF}$

## 2.7 Capacitor for boost voltage :C20


- Install a film capacitor with a rating of 0.47uF/DC450V or higher as C20.
- $\blacksquare$  If C20 is not connected, the power supply or external components may be damaged.
- Ripple current values flowing into C20 as listed in Table 2.1 are shown in Fig. 2.4.
- The frequency of the ripple current is 80 kHz to 600 kHz.
- The ripple current flows into this capacitor. Check the maximum allowable ripple current of the capacitor when selecting.
- The ripple current changes with PCB patterns, external parts, ambient temperature, etc. Check the actual ripple current value flowing through C20.





## 2.8 Inrush current limiting thermistor: TH11

- The TU series have no internal inrush current limiting circuit.
- Inrush current may possibly damage internal components. Provide a power thermistor or inrush current limiting circuit in the input line to keep inrush current below 60A. The characteristics of power thermistor as listed in Table 2.1 are shown in Fig. 2.5.
- When using a power thermistor and turning it ON/OFF repeatedly within a short period of time, keep appropriate intervals to allow the power supply to cool down sufficiently before turning on. Such intervals are also required when an inrush current limiting circuit is used.
- Inrush current values with external parts as listed in Table 2.1 are shown in Fig. 2.6.
- The inrush current changes by PCB pattern, parts characteristic etc. Check the actual inrush current value flowing through the AC line.




■ Under low temperature conditions, the output of power supply may be unstable due to high ESR values of the power thermistor and Cbc. Check with the actual device before use.

\*Refer to page A-8 for operation under low temperature conditions.



## 3. Derating

- 3.1 Input voltage derating
  - The Input voltage derating curve is shown in Fig. 3.1.




## 3.2 Output current derating

- The TU series should be conduction-cooled.
- Fig. 3.2 shows the derating curve in relation with the temperature of the aluminum base plate.

Note that operation within the shaded area will cause a significant level of ripple and ripple noise.

- Measure the temperature of the aluminum base plate at the center.
- Attention should be paid to thermal fatigue life due to temperature fluctuations by self-heating. Make the range of temperature fluctuations as narrow as possible if temperature often fluctuates.






## 4. Operation Under Low Temperature Conditions

#### 4.1 Outline of low temperature operation

- At low temperatures, output may become unstable immediately after startup or at dynamic load changes due to high ESR values of the power thermistor and Cbc. Check with the actual device before use.
- Operation becomes stable as the temperature of the power thermistor rises.
- To prevent such unstable operation, choose a low ESR capacitor as Cbc, that has sufficient capacitance within the allowable range and excellent temperature characteristics.

<Notes for operation at ambient temperatures between  $-10^{\circ}C$  and  $-40^{\circ}C$ >


- \* Avoid the gradual increase of input voltage and forced air cooling.
- \* Output voltage may remain unstable at low load current. In this case, use the minimum load current.
- \* One minute after startup, the characteristics of TH11 and Cbc become stable, which then stabilizes output.
- Fig. 4.1 shows stable operation at 25°C and unstable operation at -40°C after startup and at dynamic load changes.





## 4.2 Improvement of unstable operation

- Unstable operation can be improved by increasing the capacitance of Cbc. At low temperatures, increase the capacitance of Cbc within the range of recommended values.
- $\blacksquare$  Fig. 4.2 shows the boundary line examples of stable and unstable operation.




Startup (TUNS100)

Load 0% to 100%(TUNS100)

## 4.3 Relationship between unstable operation and input voltage

When the input voltage is low, the area for unstable operation is extended.Fig. 4.3 shows differences in operation with input voltage.




■ Page A-11 shows boundary line examples between stable and unstable operation. (Data were obtained from circuit connection shown in Fig. 2.1 with external parts shown in Table 2.1.)



## 5. Holdup Time

■ Holdup time is determined by the capacitance of Cbc. Fig. 5.1 shows the relationship between holdup time and load within the allowable capacitance of Cbc.


Fig. 5.1 Relationship between holdup time and Cbc







## 6.Appendix


Fig. A Boundary line examples between unstable and stable operation




Boundary line of stable operation at startup (TUNS50)










Boundary line of stable operation at dynamic load change from 0% to 100% (TUNS50)







Boundary line of stable operation at startup (TUNS100)



Boundary line of stable operation at dynamic load change from 0% to 100% (TUNS100)



## 7.Notes for external circuit design

■ There are notes for PWB board design at recommended circuit in this applications manual. See below.

Picture A Recommended external circuit		AC1 TUNS50 +VOU TUNS100 +VOU	© Code Cod
X Capacitor	: L11, L12 : CX1, CX2 : CY2, CY3	<ul> <li>(5) Capacitor between +BC</li> <li>(1) Aluminum Capacitor</li> <li>(2) Film Capacitor : C20</li> <li>(6) Y capacitor at BC : CY:</li> <li>(7) Output Capacitor</li> <li>(7) Output Capacitor</li> <li>(8) FG Terminal (Screw hote)</li> </ul>	$\begin{array}{c} : Cbc \\ 1 \\ . \\ . \\ . \\ . \\ . \\ . \\ . \\ . \\ .$

#### ① Input Fuse : F11

When the fuse is blown out, input voltage would be applied between the terminals of the fuse F11.

Keep the distance of the pattern between the terminals of the fuse more than 2.5mm if you must be complied safety approvals.

#### 2 Noise filter

Noise filter is build by Line filters (L11, L12), X capacitor (CX1, CX2) and Y capacitor(CY2,Y3). And the Noise filter is used to reduce conduction noise from power supply.

Off-the-shelf Noise filter is also available.

If the Line filter is placed near the components which is switching at high frequency, the conduction noise may be increased because the noise goes into the Line filter. Therefore, the Lline filter should be shielded or keep the distance from the source of noise.

The effect of noise reduction by Y capacitor depends on the place of the FG connection. Recommend connecting Y capacitor to the FG terminal of the power supply as short as possible.

Please evaluate before use.

③ Thermistor : TH11

The thermistor may become hot by the condition of the use. Keep the distance between the thermistor and other components.

(4) X Capacitor between +BC/-BC : C11

Huge ripple current flows into the X capacitor C11. Place the X capacitor near the power supply as close as possible.

(5) Capacitor between BC terminals : Cbc, C20

The high voltage(Approx. 380VDC) is applied between +BC and -BC terminals. The distance between +BC and -BC terminals must be 2.5mm or more.

Huge ripple current flows into the capacitor C20. Place C20 near the power supply as close as possible.

**(6)** Y capacitor at +BC/-BC : CY1

CY1 should be connected to the FG terminal of the power supply as short as possible.

⑦ Output Capacitor : Co, C40

Output capacitor should be near the load.

Output voltage may become unstable if the impedance of the output lines are high. In this case, add Aluminum capacitor near the +Vout/-Vout terminals.

When the output ripple and ripple noise must be reduced, ceramic capacitor C40 which has good characteristic at high frequency should be used. If through-hole type ceramic capacitor is used, the effect of the noise reduction would be reduced by the impedance of the lead frame of the components. Please evaluate before use.

(8) FG terminals of the power supply

Connect the FG terminal of the power supply to the PWB by screw. If the FG terminals of the power supply is not connected properly, malfunction or failure may happen.

Expose the solder mask around the hole of the FG connection on the PWB to connect FG terminals by screws.




Fig B.4 Example of TUNS50F TEST BOARD