

ABNORMAL TEST RESULT

OF MODEL PCA600F-□-P2

1. Did Cheese Cloth or Paper Glow?

No.

2. Did Ground Fuse Open?

No.

3. Dielectric breakdown?

No.

4. Other Results?

See the following pages .

(FMEA : 2/88 ~ 80/88)

(Abnormal Test Result: 81/88 ~ 88/88)

There was no emission of flame, molten metal, ignition of cheesecloth, dielectric breakdown, opening of the ground fuse, other indication of a shock or fire hazard.

F M E A

Component	Mode	Comment	Output Voltage (V)
C101	Open	Normal operation.	AVR1:*
	Short	F101, F102 opend, No hazard.	AVR1:0
C102	Open	Normal operation.	AVR1:*
	Short	F101, F102 opend, No hazard.	AVR1:0
C103	Open	See 81 Page.	
	Short	F101, F102 opend, No hazard.	AVR1:0
C107	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C108	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C109	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C110	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C115	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C116	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C117	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C118	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C131	Open	Normal operation.	AVR1:*
	Short	F101, F102 opend, No hazard.	AVR1:0

F M E A

Component	Mode	Comment	Output Voltage (V)
C132	Open	Normal operation.	AVR1:*
	Short	F101, F102 opend, No hazard.	AVR1:0
C133	Open	Normal operation.	AVR1:*
	Short	F101, F102 opend, No hazard.	AVR1:0
C134	Open	Normal operation.	AVR1:*
	Short	F101, F102 opend, No hazard.	AVR1:0
C150	Open	Normal operation.	AVR1:*
	Short	No hazard.	AVR1:0
C151	Open	Normal operation.	AVR1:*
	Short	See 81 Page.	
C152	Open	Normal operation.	AVR1:*
	Short	See 81 Page.	
C153	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C154	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C155	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C156	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C157	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C158	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0

F M E A

Component	Mode	Comment	Output Voltage (V)
C159	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C160	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C161	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C162	Open	Normal operation.	AVR1:*
	Short	See 81 Page.	
C181	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C201	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C202	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C203	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
C204	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C205	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C206	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
C207	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0

F M E A

Component	Mode	Comment	Output Voltage (V)
C211	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C212	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C213	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C214	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C221	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C222	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C223	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C224	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C225	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C226	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C241	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
C251	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
C252	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C253	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C254	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C301	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C302	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C303	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C304	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C305	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C311	Open	No Hazard.	AVR1:*
	Short	No Hazard.	AVR1:*
C312	Open	No Hazard.	AVR1:*
	Short	No Hazard.	AVR1:*
C321	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C323	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
C331	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C332	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C333	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C334	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C335	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
C341	Open	Output voltage decreased. No hazard.	AVR1:decreased
	Short	See 81 Page.	
C342	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C343	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C344	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C345	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C346	Open	See 81 Page.	
	Short	Output voltage decreased. No hazard.	AVR1:decreased
C351	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0

F M E A

Component	Mode	Comment	Output Voltage (V)
C352	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C353	Open	No Hazard.	AVR1:0
	Short	Output voltage increased. No hazard.	AVR1:increased
C354	Open	Output voltage decreased. No hazard.	AVR1:decreased
	Short	Normal operation.	AVR1:*
C355	Open	Output voltage decreased. No hazard.	AVR1:decreased
	Short	No Hazard.	AVR1:0
C357	Open	No Hazard.	AVR1:*
	Short	No Hazard.	AVR1:*
C358	Open	No Hazard.	AVR1:*
	Short	No Hazard.	AVR1:*
C360	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C362	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C363	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C364	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C367	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C372	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased

F M E A

Component	Mode	Comment	Output Voltage (V)
C373	Open	Normal operation.	AVR1:*
	Short	Output voltage increased. No hazard.	AVR1:increased(130%)
C381	Open	Normal operation.	AVR1:*
	Short	See 81 Page.	
C382	Open	Normal operation.	AVR1:*
	Short	See 81 Page.	
C383	Open	Normal operation.	AVR1:*
	Short	See 81 Page.	
C384	Open	Normal operation.	AVR1:*
	Short	See 81 Page.	
C391	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C392	Open	See 81 Page.	
	Short	See 81 Page.	
C393	Open	Normal operation.	AVR1:*
	Short	See 81 Page.	
C394	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C395	Open	See 81 Page.	
	Short	See 81 Page.	
C396	Open	Normal operation.	AVR1:*
	Short	See 81 Page.	
C401	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
C402	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C403	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C404	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C405	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C421	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C422	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C423	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C424	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C425	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C501	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
C502	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
C511	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased

F M E A

Component	Mode	Comment	Output Voltage (V)
C512	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
C513	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
C514	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
C521	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C522	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C523	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C524	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C531	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C532	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C533	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C534	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C541	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased

F M E A

Component	Mode	Comment	Output Voltage (V)
C542	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
C543	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
C544	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
C551	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C552	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C553	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C554	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C561	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C562	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C563	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C564	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C601	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
C602	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C603	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C604	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C605	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C606	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C611	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C613	Open	No Hazard.	AVR1:0
	Short	No Hazard.	AVR1:0
C614	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C615	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C621	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C623	Open	No Hazard.	AVR1:0
	Short	No Hazard.	AVR1:0
C624	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0

F M E A

Component	Mode	Comment	Output Voltage (V)
C625	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C633	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C634	Open	No Hazard.	AVR1:0
	Short	No Hazard.	AVR1:0
C635	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C661	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C662	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C663	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C664	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C665	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C666	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C691	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C692	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
C701	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C702	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C703	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C704	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C705	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C706	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C707	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C708	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C709	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C721	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C722	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C723	Open	Output voltage decreased. No hazard.	AVR1:decreased
	Short	Output voltage decreased. No hazard.	AVR1:decreased

F M E A

Component	Mode	Comment	Output Voltage (V)
C724	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
C725	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C726	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C727	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C728	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C729	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C732	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C733	Open	Output voltage decreased. No hazard.	AVR1:decreased
	Short	Output voltage decreased. No hazard.	AVR1:decreased
C734	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
C735	Open	Output voltage decreased. No hazard.	AVR1:decreased
	Short	Output voltage decreased. No hazard.	AVR1:decreased
C736	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C749	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
C750	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C751	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C752	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C753	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C754	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C755	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C756	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C760	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C761	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
C762	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C763	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C764	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
C765	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
C766	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C791	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C792	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C801	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C802	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C803	Open	No Hazard.	AVR1:0
	Short	No Hazard.	AVR1:*
C804	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C805	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C806	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C807	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C808	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0

F M E A

Component	Mode	Comment	Output Voltage (V)
C831	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C832	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C833	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C901	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C902	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C903	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C904	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C905	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C906	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C911	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:*
C912	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C913	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
C914	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C920	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C921	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C922	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C931	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C941	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C942	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C943	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C944	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C951	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C952	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C953	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
C954	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
D101	Open	No Hazard.	AVR1:0
	Short	Normal operation.	AVR1:*
D102	Open	No Hazard.	AVR1:0
	Short	Normal operation.	AVR1:*
D103	Open	No Hazard.	AVR1:0
	Short	Normal operation.	AVR1:*
D104	Open	No Hazard.	AVR1:0
	Short	Normal operation.	AVR1:*
D105	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
D106	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
D107	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
D108	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
D111	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
D112	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
D113	Open	Normal operation.	AVR1:*
	Short	See 81 Page.	

F M E A

Component	Mode	Comment	Output Voltage (V)
D114	Open	Normal operation.	AVR1:*
	Short	See 81 Page.	
D115	Open	Normal operation.	AVR1:*
	Short	See 81 Page.	
D116	Open	Normal operation.	AVR1:*
	Short	See 81 Page.	
D117	Open	Normal operation.	AVR1:*
	Short	See 81 Page.	
D118	Open	Normal operation.	AVR1:*
	Short	See 81 Page.	
D151	Open	Normal operation.	AVR1:*
	Short	See 81 Page.	
D152	Open	Normal operation.	AVR1:*
	Short	See 81 Page.	
D222	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
D241	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
D242	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
D301	Open	Output voltage decreased. No hazard.	AVR1:decreased
	Short	See 82 Page.	
D303	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
D304	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
D305	Open	No Hazard.	AVR1:0
	Short	Output voltage decreased. No hazard.	AVR1:decreased
D331	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
D341	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
D342	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
D343	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
D344	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
D351	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
D352	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
D353	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
D381	Open	See 82 Page.	
	Short	Output voltage decreased. No hazard.	AVR1:decreased
D382	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
D383	Open	See 82 Page.	
	Short	Output voltage decreased. No hazard.	AVR1:decreased
D384	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
D401	Open	No Hazard.	AVR1:*
	Short	No Hazard.	AVR1:*
D421	Open	No Hazard.	AVR1:0
	Short	No Hazard.	AVR1:0
D422	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:*
D601	Open	No Hazard.	AVR1:0
	Short	No Hazard.	AVR1:0
D602	Open	No Hazard.	AVR1:0
	Short	No Hazard.	AVR1:0
D603	Open	No Hazard.	AVR1:0
	Short	No Hazard.	AVR1:0
D701	Open	No Hazard.	AVR1:0
	Short	No Hazard.	AVR1:0
D721	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
D722	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
D751	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*

F M E A

Component	Mode		Comment	Output Voltage (V)
D761	Open		Normal operation.	AVR1:*
	Short		Normal operation.	AVR1:*
D781	Open		Normal operation.	AVR1:*
	Short		Normal operation.	AVR1:*
D801	Open		No Hazard.	AVR1:*
	Short		No Hazard.	AVR1:0
D802	Open		Normal operation.	AVR1:*
	Short		No Hazard.	AVR1:0
D831	Open		Normal operation.	AVR1:*
	Short		No Hazard.	AVR1:0
D832	Open		Normal operation.	AVR1:*
	Short		Normal operation.	AVR1:*
D911	Open		No Hazard.	AVR1:*
	Short		No Hazard.	AVR1:*
D931	Open		Normal operation.	AVR1:*
	Short		Normal operation.	AVR1:*
D951	Open		Normal operation.	AVR1:*
	Short		Normal operation.	AVR1:*
D952	Open		Normal operation.	AVR1:*
	Short		Normal operation.	AVR1:*
FAN801	Open	1	No Hazard.	AVR1:0
		2	No Hazard.	AVR1:0
		3	No Hazard.	AVR1:0
	Short	1-2	No Hazard.	AVR1:0

F M E A

Component	Mode		Comment	Output Voltage (V)
FAN801	Short	2-3	No Hazard.	AVR1:0
IC101	Open	1	See 82 Page.	
		2	No Hazard.	AVR1:0
		3	Normal operation.	AVR1:*
		4	See 82 Page.	
		5	Normal operation.	AVR1:*
		6	Output voltage decreased. No hazard.	AVR1:decreased
		7	No Hazard.	AVR1:0
		8	No Hazard.	AVR1:0
		9	Normal operation.	AVR1:*
		10	Normal operation.	AVR1:*
		11	See 82 Page.	
		12	No Hazard.	AVR1:0
		13	Normal operation.	AVR1:*
		14	See 82 Page.	
		15	Normal operation.	AVR1:*
		16	See 82 Page.	
	Short	1-2	No Hazard.	AVR1:0
		2-3	No Hazard.	AVR1:0
		3-4	Normal operation.	AVR1:*
		4-5	Normal operation.	AVR1:*
		5-6	No Hazard.	AVR1:0
		6-7	No Hazard.	AVR1:0
		7-8	Normal operation.	AVR1:*

F M E A

Component	Mode		Comment	Output Voltage (V)
IC101	Short	9-10	Normal operation.	AVR1:*
		10-11	See 82 Page.	
		11-12	No Hazard.	AVR1:0
		12-13	No hazard.	AVR1:0
		13-14	See 82 Page.	
		14-15	No Hazard.	AVR1:0
		15-16	No Hazard.	AVR1:0
IC151	Open	1	Normal operation.	AVR1:*
		2	Normal operation.	AVR1:*
		3	Normal operation.	AVR1:*
		4	Normal operation.	AVR1:*
		5	Normal operation.	AVR1:*
	Short	1-2	Normal operation.	AVR1:*
		2-3	Normal operation.	AVR1:*
		4-5	Normal operation.	AVR1:*
IC201	Open	1	Normal operation.	AVR1:*
		2	Normal operation.	AVR1:*
		3	Normal operation.	AVR1:*
		4	Output voltage decreased. No hazard.	AVR1:decreased
		5	Normal operation.	AVR1:*
		6	Output voltage decreased. No hazard.	AVR1:decreased
		7	No Hazard.	AVR1:0
		8	Normal operation.	AVR1:*
		9	Output voltage decreased. No hazard.	AVR1:decreased

F M E A

Component	Mode		Comment	Output Voltage (V)
IC201	Open	10	Output voltage decreased. No hazard.	AVR1:decreased
		11	Normal operation.	AVR1:*
		12	Normal operation.	AVR1:*
		13	No Hazard.	AVR1:0
		14	No Hazard.	AVR1:0
		15	Normal operation.	AVR1:*
		16	Normal operation.	AVR1:*
		17	Normal operation.	AVR1:*
		18	Output voltage decreased. No hazard.	AVR1:decreased
		19	Normal operation.	AVR1:*
		20	Output voltage decreased. No hazard.	AVR1:decreased
		21	Normal operation.	AVR1:*
		22	Normal operation.	AVR1:*
		23	Normal operation.	AVR1:*
		24	No Hazard.	AVR1:0
		25	Output voltage decreased. No hazard.	AVR1:decreased
		26	Output voltage decreased. No hazard.	AVR1:decreased
		27	Output voltage decreased. No hazard.	AVR1:decreased
		28	Output voltage decreased. No hazard.	AVR1:decreased
		29	Normal operation.	AVR1:*
		30	No Hazard.	AVR1:0
		31	No Hazard.	AVR1:0
		32	Output voltage decreased. No hazard.	AVR1:decreased
		33	Normal operation.	AVR1:*

F M E A

Component	Mode		Comment	Output Voltage (V)
IC201	Open	34	Normal operation.	AVR1:*
		35	Normal operation.	AVR1:*
		36	Normal operation.	AVR1:*
		37	Output voltage decreased. No hazard.	AVR1:decreased
		38	No Hazard.	AVR1:0
	Short	1-2	Normal operation.	AVR1:*
		2-3	Normal operation.	AVR1:*
		3-4	Normal operation.	AVR1:*
		4-5	Normal operation.	AVR1:*
		5-6	Normal operation.	AVR1:*
		6-7	Normal operation.	AVR1:*
		7-8	No Hazard.	AVR1:0
		8-9	Output voltage decreased. No hazard.	AVR1:decreased
		9-10	Normal operation.	AVR1:*
		10-11	Output voltage decreased. No hazard.	AVR1:decreased
		11-12	No Hazard.	AVR1:0
		12-13	No Hazard.	AVR1:0
		13-14	No Hazard.	AVR1:0
		14-15	No Hazard.	AVR1:*
		15-16	Output voltage decreased. No hazard.	AVR1:decreased
		16-17	Output voltage decreased. No hazard.	AVR1:decreased
		17-18	Output voltage decreased. No hazard.	AVR1:decreased
		18-19	Output voltage decreased. No hazard.	AVR1:decreased
		20-21	Output voltage decreased. No hazard.	AVR1:decreased

F M E A

Component	Mode		Comment	Output Voltage (V)
IC201	Short	21-22	Output voltage decreased. No hazard.	AVR1:decreased
		22-23	Normal operation.	AVR1:*
		23-24	Output voltage decreased. No hazard.	AVR1:decreased
		24-25	Output voltage decreased. No hazard.	AVR1:decreased
		25-26	Output voltage decreased. No hazard.	AVR1:decreased
		26-27	Output voltage decreased. No hazard.	AVR1:decreased
		27-28	Output voltage decreased. No hazard.	AVR1:decreased
		28-29	See 82 Page.	
		29-30	No Hazard.	AVR1:0
		30-31	No Hazard.	AVR1:0
		31-32	No Hazard.	AVR1:0
		32-33	Output voltage decreased. No hazard.	AVR1:decreased
		33-34	Output voltage decreased. No hazard.	AVR1:decreased
		34-35	Output voltage decreased. No hazard.	AVR1:decreased
		35-36	Output voltage decreased. No hazard.	AVR1:decreased
		36-37	Output voltage decreased. No hazard.	AVR1:decreased
		37-38	Output voltage decreased. No hazard.	AVR1:decreased
IC202	Open	1	Normal operation.	AVR1:*
		2	Normal operation.	AVR1:*
		3	Normal operation.	AVR1:*
		4	Normal operation.	AVR1:*
		5	Normal operation.	AVR1:*
		6	Normal operation.	AVR1:*
		7	Normal operation.	AVR1:*

F M E A

Component	Mode		Comment	Output Voltage (V)
IC202	Open	8	No Hazard.	AVR1:0
	Short	1-2	Normal operation.	AVR1:*
		2-3	No Hazard.	AVR1:0
		3-4	Normal operation.	AVR1:*
		5-6	Normal operation.	AVR1:*
		6-7	Normal operation.	AVR1:*
		7-8	No Hazard.	AVR1:0
IC221	Open	1	Normal operation.	AVR1:*
		2	Normal operation.	AVR1:*
		3	Normal operation.	AVR1:*
		4	Normal operation.	AVR1:*
		5	Normal operation.	AVR1:*
	Short	1-2	Normal operation.	AVR1:*
		2-3	Normal operation.	AVR1:*
		4-5	Normal operation.	AVR1:*
IC301	Open	1	Output voltage decreased. No hazard.	AVR1:decreased
		2	Normal operation.	AVR1:*
		3	Output voltage decreased. No hazard.	AVR1:decreased
		4	Normal operation.	AVR1:*
		5	Output voltage decreased. No hazard.	AVR1:decreased
		6	Output voltage decreased. No hazard.	AVR1:decreased
		7	Output voltage decreased. No hazard.	AVR1:decreased
		8	Output voltage decreased. No hazard.	AVR1:decreased
	Short	1-2	Output voltage decreased. No hazard.	AVR1:decreased

F M E A

Component	Mode		Comment	Output Voltage (V)
IC301	Short	2-3	Normal operation.	AVR1:*
		3-4	Normal operation.	AVR1:*
		5-6	No Hazard.	AVR1:0
		6-7	Output voltage decreased. No hazard.	AVR1:decreased
		7-8	See 82 Page.	
IC311	Open	1	Normal operation.	AVR1:*
		2	Normal operation.	AVR1:*
		3	Output voltage decreased. No hazard.	AVR1:decreased
		4	See 82 Page.	
		5	See 82 Page.	
		6	See 82 Page.	
		7	See 82 Page.	
		8	See 82 Page.	
	Short	1-2	Normal operation.	AVR1:*
		2-3	See 82 Page.	
		3-4	See 82 Page.	
		5-6	Output voltage decreased. No hazard.	AVR1:decreased
		6-7	See 82 Page.	
		7-8	See 82 Page.	
IC312	Open	1	Normal operation.	AVR1:*
		2	Normal operation.	AVR1:*
		3	Output voltage decreased. No hazard.	AVR1:decreased
		4	See 82 Page.	
		5	See 82 Page.	

F M E A

Component	Mode		Comment	Output Voltage (V)
IC312	Open	6	See 82 Page.	
		7	See 83 Page.	
		8	See 83 Page.	
	Short	1-2	Normal operation.	AVR1:*
		2-3	See 83 Page.	
		3-4	See 83 Page.	
		5-6	Output voltage decreased. No hazard.	AVR1:decreased
		6-7	See 83 Page.	
		7-8	See 83 Page.	
IC361	Open	1	Output voltage decreased. No hazard.	AVR1:decreased
		2	Output voltage decreased. No hazard.	AVR1:decreased
		3	Output voltage decreased. No hazard.	AVR1:decreased
		4	Normal operation.	AVR1:*
		5	Output voltage decreased. No hazard.	AVR1:decreased
	Short	1-2	Output voltage decreased. No hazard.	AVR1:decreased
		2-3	Output voltage decreased. No hazard.	AVR1:decreased
		4-5	Output voltage decreased. No hazard.	AVR1:decreased
IC401	Open	C	No Hazard.	AVR1:0
		S	No Hazard.	AVR1:0
		D	No Hazard.	AVR1:0
	Short	C-S	No Hazard.	AVR1:0
		D-S	See 83 Page.	
		D-C	No Hazard.	AVR1:0
IC701	Open	1	Normal operation.	AVR1:*

F M E A

Component	Mode		Comment	Output Voltage (V)
IC701	Open	2	No Hazard.	AVR1:0
		3	No Hazard.	AVR1:0
		4	No Hazard.	AVR1:0
		5	Normal operation.	AVR1:*
		6	No Hazard.	AVR1:0
		7	Normal operation.	AVR1:*
		8	No Hazard.	AVR1:0
		9	Normal operation.	AVR1:*
		10	Normal operation.	AVR1:*
		11	Normal operation.	AVR1:*
		12	No Hazard.	AVR1:0
		13	No Hazard.	AVR1:0
		14	No Hazard.	AVR1:0
		15	Normal operation.	AVR1:*
		16	Normal operation.	AVR1:*
		17	Normal operation.	AVR1:*
		18	Normal operation.	AVR1:*
		19	Normal operation.	AVR1:*
		20	No Hazard.	AVR1:0
		21	Normal operation.	AVR1:*
		22	Normal operation.	AVR1:*
		23	Normal operation.	AVR1:*
		24	Normal operation.	AVR1:*
		25	Normal operation.	AVR1:*

F M E A

Component	Mode		Comment	Output Voltage (V)
IC701	Open	26	Output voltage decreased. No hazard.	AVR1:decreased
		27	Normal operation.	AVR1:*
		28	Normal operation.	AVR1:*
		29	Normal operation.	AVR1:*
		30	Normal operation.	AVR1:*
		31	Normal operation.	AVR1:*
		32	Normal operation.	AVR1:*
		33	Normal operation.	AVR1:*
		34	Output voltage decreased. No hazard.	AVR1:decreased
		35	Normal operation.	AVR1:*
		36	Normal operation.	AVR1:*
		37	Normal operation.	AVR1:*
		38	No Hazard.	AVR1:0
	Short	1-2	No Hazard.	AVR1:0
		2-3	No Hazard.	AVR1:0
		3-4	No Hazard.	AVR1:0
		4-5	Output voltage increased. No hazard.	AVR1:increased(130%)
		5-6	Normal operation.	AVR1:*
		6-7	No Hazard.	AVR1:0
		7-8	No Hazard.	AVR1:0
		8-9	Normal operation.	AVR1:*
		9-10	Normal operation.	AVR1:*
		10-11	Normal operation.	AVR1:*
		11-12	Normal operation.	AVR1:*

F M E A

Component	Mode		Comment	Output Voltage (V)
IC701	Short	12-13	No Hazard.	AVR1:0
		13-14	No Hazard.	AVR1:0
		14-15	Normal operation.	AVR1:*
		15-16	Normal operation.	AVR1:*
		16-17	Normal operation.	AVR1:*
		17-18	Normal operation.	AVR1:*
		18-19	Normal operation.	AVR1:*
		20-21	No Hazard.	AVR1:0
		21-22	Normal operation.	AVR1:*
		22-23	Normal operation.	AVR1:*
		23-24	Normal operation.	AVR1:*
		24-25	Output voltage decreased. No hazard.	AVR1:decreased
		25-26	Output voltage decreased. No hazard.	AVR1:decreased
		26-27	Output voltage decreased. No hazard.	AVR1:decreased
		27-28	Normal operation.	AVR1:*
		28-29	Normal operation.	AVR1:*
		29-30	Normal operation.	AVR1:*
		30-31	Normal operation.	AVR1:*
		31-32	Normal operation.	AVR1:*
		32-33	Normal operation.	AVR1:*
		33-34	Normal operation.	AVR1:*
		34-35	Output voltage decreased. No hazard.	AVR1:decreased
		35-36	Normal operation.	AVR1:*
		36-37	Normal operation.	AVR1:*

F M E A

Component	Mode		Comment	Output Voltage (V)
IC701	Short	37-38	Normal operation.	AVR1:*
IC702	Open	1	Normal operation.	AVR1:*
		2	Normal operation.	AVR1:*
		3	No Hazard.	AVR1:0
		4	No Hazard.	AVR1:0
		5	No Hazard.	AVR1:0
	Short	1-2	Normal operation.	AVR1:*
		2-3	Normal operation.	AVR1:*
		4-5	No Hazard.	AVR1:0
IC703	Open	1	No Hazard.	AVR1:0
		2	Output voltage decreased. No hazard.	AVR1:decreased
		3	Normal operation.	AVR1:*
		4	No Hazard.	AVR1:0
		5	Normal operation.	AVR1:*
		6	Output voltage decreased. No hazard.	AVR1:decreased
		7	Output voltage decreased. No hazard.	AVR1:decreased
		8	No Hazard.	AVR1:0
	Short	1-2	Normal operation.	AVR1:*
		2-3	No Hazard.	AVR1:0
		3-4	Normal operation.	AVR1:*
		5-6	Output voltage decreased. No hazard.	AVR1:decreased
		6-7	Normal operation.	AVR1:*
		7-8	No Hazard.	AVR1:0
IC721	Open	1	No Hazard.	AVR1:0

F M E A

Component	Mode		Comment	Output Voltage (V)
IC721	Open	2	No Hazard.	AVR1:0
		3	No Hazard.	AVR1:0
		4	No Hazard.	AVR1:0
		5	No Hazard.	AVR1:0
	Short	1-2	No Hazard.	AVR1:0
		2-3	No Hazard.	AVR1:0
		4-5	No Hazard.	AVR1:0
IC722	Open	1	Normal operation.	AVR1:*
		2	Output voltage decreased. No hazard.	AVR1:decreased
		3	Output voltage decreased. No hazard.	AVR1:decreased
		4	Output voltage decreased. No hazard.	AVR1:decreased
		5	Output voltage decreased. No hazard.	AVR1:decreased
	Short	1-2	Normal operation.	AVR1:*
		2-3	Output voltage increased. No hazard.	AVR1:increased(130%)
		4-5	Output voltage increased. No hazard.	AVR1:increased(130%)
IC723	Open	1	No Hazard.	AVR1:0
		2	No Hazard.	AVR1:0
		3	Output voltage decreased. No hazard.	AVR1:decreased
		4	Output voltage decreased. No hazard.	AVR1:decreased
		5	No Hazard.	AVR1:0
	Short	1-2	No Hazard.	AVR1:0
		2-3	Output voltage decreased. No hazard.	AVR1:decreased
		4-5	Output voltage decreased. No hazard.	AVR1:decreased
IC761	Open	1	Normal operation.	AVR1:*

F M E A

Component	Mode		Comment	Output Voltage (V)
IC761	Open	2	Normal operation.	AVR1:*
		3	Normal operation.	AVR1:*
		4	Normal operation.	AVR1:*
		5	Normal operation.	AVR1:*
	Short	1-2	Normal operation.	AVR1:*
		2-3	Normal operation.	AVR1:*
		4-5	No Hazard.	AVR1:0
IC801	Open	1	Normal operation.	AVR1:*
		2	No Hazard.	AVR1:0
		3	No Hazard.	AVR1:0
		4	No Hazard.	AVR1:0
		5	No Hazard.	AVR1:0
	Short	1-2	Normal operation.	AVR1:*
		2-3	No Hazard.	AVR1:0
		4-5	No Hazard.	AVR1:0
IC805	Open	1	Normal operation.	AVR1:*
		2	Normal operation.	AVR1:*
		3	Normal operation.	AVR1:*
		4	Normal operation.	AVR1:*
		5	Normal operation.	AVR1:*
	Short	1-2	Normal operation.	AVR1:*
		2-3	Normal operation.	AVR1:*
		4-5	Normal operation.	AVR1:*
IC831	Open	1	Normal operation.	AVR1:*

F M E A

Component	Mode		Comment	Output Voltage (V)
IC831	Open	2	Normal operation.	AVR1:*
		3	Normal operation.	AVR1:*
		4	Normal operation.	AVR1:*
		5	Normal operation.	AVR1:*
		6	No Hazard.	AVR1:*
		7	No Hazard.	AVR1:*
		8	Normal operation.	AVR1:*
	Short	1-2	Normal operation.	AVR1:*
		2-3	Normal operation.	AVR1:*
		3-4	Normal operation.	AVR1:*
		5-6	Normal operation.	AVR1:*
		6-7	Normal operation.	AVR1:*
		7-8	No Hazard.	AVR1:0
L101	Open	1	No Hazard.	AVR1:0
		2	No Hazard.	AVR1:0
		3	No Hazard.	AVR1:0
		4	No Hazard.	AVR1:0
	Short	1-2	Normal operation.	AVR1:*
		3-4	Normal operation.	AVR1:*
L102	Open		No Hazard.	AVR1:0
	Short		Normal operation.	AVR1:*
L103	Open	1	See 83 Page.	
		2	See 83 Page.	
		3	See 83 Page.	

F M E A

Component	Mode		Comment	Output Voltage (V)
L103	Open	4	See 83 Page.	
		5	See 83 Page.	
		6	See 83 Page.	
		7	See 83 Page.	
	Short	1-2	F101, F102 opend, No hazard.	AVR1:0
		2-3	F101, F102 opend, No hazard.	AVR1:0
		5-6	See 83 Page.	
		6-7	See 83 Page.	
L301	Open		Output voltage decreased. No hazard.	AVR1:decreased
	Short		F101, F102 opend, No hazard.	AVR1:0
L801	Open		No Hazard.	AVR1:0
	Short		No Hazard.	AVR1:*
L951	Open		Normal operation.	AVR1:*
	Short		Normal operation.	AVR1:*
LED701	Open		Normal operation.	AVR1:*
	Short		Normal operation.	AVR1:*
LED702	Open		Normal operation.	AVR1:*
	Short		Normal operation.	AVR1:*
PC201	Open	A, K	Normal operation.	AVR1:*
		C, E	Normal operation.	AVR1:*
	Short	A-K	Normal operation.	AVR1:*
		C-E	Normal operation.	AVR1:*
PC202	Open	A, K	Normal operation.	AVR1:*
		C, E	Normal operation.	AVR1:*

F M E A

Component	Mode		Comment	Output Voltage (V)
PC202	Short	A-K	Normal operation.	AVR1:*
		C-E	Normal operation.	AVR1:*
PC203	Open	1	No Hazard.	AVR1:0
		3	No Hazard.	AVR1:0
		4	No Hazard.	AVR1:0
		5	No Hazard.	AVR1:0
		6	No Hazard.	AVR1:0
	Short	1-3	No Hazard.	AVR1:0
		4-5	No Hazard.	AVR1:0
		5-6	No Hazard.	AVR1:0
PC204	Open	1	No Hazard.	AVR1:0
		3	No Hazard.	AVR1:0
		4	No Hazard.	AVR1:0
		5	No Hazard.	AVR1:0
		6	No Hazard.	AVR1:0
	Short	1-3	No Hazard.	AVR1:0
		4-5	No Hazard.	AVR1:0
		5-6	No Hazard.	AVR1:0
PC205	Open	A, K	Normal operation.	AVR1:*
		C, E	Normal operation.	AVR1:*
	Short	A-K	Normal operation.	AVR1:*
		C-E	No Hazard.	AVR1:0
PC301	Open	A, K	Output voltage increased. No hazard.	AVR1:increased (130%)
		C, E	Output voltage increased. No hazard.	AVR1:increased (130%)

F M E A

Component	Mode		Comment	Output Voltage (V)
PC301	Short	A-K	Output voltage increased. No hazard.	AVR1:increased(130%)
		C-E	Output voltage decreased. No hazard.	AVR1:decreased
PC401	Open	A, K	No Hazard.	AVR1:0
		C, E	No Hazard.	AVR1:0
	Short	A-K	No Hazard.	AVR1:0
		C-E	No Hazard.	AVR1:0
PC601	Open	1	No Hazard.	AVR1:0
		3	No Hazard.	AVR1:0
		4	No Hazard.	AVR1:0
		5	No Hazard.	AVR1:0
		6	No Hazard.	AVR1:0
	Short	1-3	No Hazard.	AVR1:0
		4-5	No Hazard.	AVR1:0
		5-6	No Hazard.	AVR1:0
PC602	Open	1	No Hazard.	AVR1:0
		3	No Hazard.	AVR1:0
		4	No Hazard.	AVR1:0
		5	No Hazard.	AVR1:0
		6	No Hazard.	AVR1:0
	Short	1-3	No Hazard.	AVR1:0
		4-5	No Hazard.	AVR1:0
		5-6	No Hazard.	AVR1:0
PC701	Open	A, K	Normal operation.	AVR1:*
		C, E	Normal operation.	AVR1:*

F M E A

Component	Mode		Comment	Output Voltage (V)
PC701	Short	A-K	Normal operation.	AVR1:*
		C-E	Normal operation.	AVR1:*
PC781	Open	A, K	No Hazard.	AVR1:0
		C, E	No Hazard.	AVR1:0
	Short	A-K	No Hazard.	AVR1:0
		C-E	No Hazard.	AVR1:0
PC782	Open	A, K	No Hazard.	AVR1:0
		C, E	No Hazard.	AVR1:0
	Short	A-K	No Hazard.	AVR1:0
		C-E	No Hazard.	AVR1:0
PC802	Open	A, K	Normal operation.	AVR1:*
		C, E	Normal operation.	AVR1:*
	Short	A-K	Normal operation.	AVR1:*
		C-E	Normal operation.	AVR1:*
PC803	Open	A, K	Normal operation.	AVR1:*
		C, E	Normal operation.	AVR1:*
	Short	A-K	Normal operation.	AVR1:*
		C-E	Normal operation.	AVR1:*
PC804	Open	A, K	Normal operation.	AVR1:*
		C, E	Normal operation.	AVR1:*
	Short	A-K	Normal operation.	AVR1:*
		C-E	Normal operation.	AVR1:*
PTH301	Open		Output voltage decreased. No hazard.	AVR1:decreased
	Short		Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
R101	Open	Normal operation.	AVR1:*
R102	Open	No Hazard.	AVR1:0
R103	Open	No Hazard.	AVR1:0
R104	Open	No Hazard.	AVR1:0
R105	Open	No Hazard.	AVR1:0
R106	Open	No Hazard.	AVR1:0
R109	Open	No Hazard.	AVR1:0
R110	Open	No Hazard.	AVR1:0
R111	Open	No Hazard.	AVR1:0
R112	Open	Normal operation.	AVR1:*
R113	Open	Normal operation.	AVR1:*
R114	Open	Normal operation.	AVR1:*
R115	Open	Normal operation.	AVR1:*
R116	Open	Normal operation.	AVR1:*
R117	Open	Normal operation.	AVR1:*
R121	Open	Normal operation.	AVR1:*
R122	Open	See 83 Page.	
R123	Open	Normal operation.	AVR1:*
R124	Open	Normal operation.	AVR1:*
R125	Open	Normal operation.	AVR1:*
R126	Open	Normal operation.	AVR1:*
R127	Open	See 83 Page.	
R128	Open	Normal operation.	AVR1:*
R129	Open	Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
R130	Open	Normal operation.	AVR1:*
R140	Open	No Hazard.	AVR1:0
R141	Open	No Hazard.	AVR1:0
R142	Open	No Hazard.	AVR1:0
R143	Open	No Hazard.	AVR1:0
R144	Open	No Hazard.	AVR1:0
R145	Open	No Hazard.	AVR1:0
R150	Open	No Hazard.	AVR1:0
R151	Open	See 83 Page.	
R152	Open	See 83 Page.	
R153	Open	Normal operation.	AVR1:*
R154	Open	Normal operation.	AVR1:*
R155	Open	Normal operation.	AVR1:*
R156	Open	Normal operation.	AVR1:*
R158	Open	Normal operation.	AVR1:*
R159	Open	Normal operation.	AVR1:*
R160	Open	Normal operation.	AVR1:*
R161	Open	Normal operation.	AVR1:*
R162	Open	Normal operation.	AVR1:*
R163	Open	Normal operation.	AVR1:*
R164	Open	Normal operation.	AVR1:*
R165	Open	No Hazard.	AVR1:0
R166	Open	No Hazard.	AVR1:0
R167	Open	No Hazard.	AVR1:0

F M E A

Component	Mode	Comment	Output Voltage (V)
R168	Open	No Hazard.	AVR1:0
R169	Open	No Hazard.	AVR1:0
R170	Open	No Hazard.	AVR1:0
R171	Open	Normal operation.	AVR1:*
R172	Open	Normal operation.	AVR1:*
R173	Open	Normal operation.	AVR1:*
R174	Open	No Hazard.	AVR1:0
R175	Open	Normal operation.	AVR1:*
R180	Open	Normal operation.	AVR1:*
R181	Open	Normal operation.	AVR1:*
R182	Open	Normal operation.	AVR1:*
R183	Open	No Hazard.	AVR1:0
R184	Open	No Hazard.	AVR1:0
R185	Open	Normal operation.	AVR1:*
R201	Open	No Hazard.	AVR1:0
R202	Open	Output voltage decreased. No hazard.	AVR1:decreased
R203	Open	Normal operation.	AVR1:*
R207	Open	No Hazard.	AVR1:0
R211	Open	No Hazard.	AVR1:0
R212	Open	No Hazard.	AVR1:0
R213	Open	Normal operation.	AVR1:*
R220	Open	Normal operation.	AVR1:*
R221	Open	Normal operation.	AVR1:*
R222	Open	Output voltage decreased. No hazard.	AVR1:decreased

F M E A

Component	Mode	Comment	Output Voltage (V)
R223	Open	Normal operation.	AVR1:*
R224	Open	Normal operation.	AVR1:*
R225	Open	Output voltage decreased. No hazard.	AVR1:decreased
R226	Open	Output voltage decreased. No hazard.	AVR1:decreased
R227	Open	No Hazard.	AVR1:0
R228	Open	Normal operation.	AVR1:*
R240	Open	Normal operation.	AVR1:*
R241	Open	Output voltage decreased. No hazard.	AVR1:decreased
R242	Open	Normal operation.	AVR1:*
R243	Open	No Hazard.	AVR1:0
R244	Open	No Hazard.	AVR1:0
R245	Open	No Hazard.	AVR1:0
R246	Open	No Hazard.	AVR1:0
R251	Open	Normal operation.	AVR1:*
R252	Open	No Hazard.	AVR1:0
R253	Open	No Hazard.	AVR1:0
R254	Open	Normal operation.	AVR1:*
R301	Open	Normal operation.	AVR1:*
R302	Open	Normal operation.	AVR1:*
R303	Open	Normal operation.	AVR1:*
R304	Open	Normal operation.	AVR1:*
R305	Open	Normal operation.	AVR1:*
R306	Open	Normal operation.	AVR1:*
R307	Open	Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
R308	Open	Normal operation.	AVR1:*
R311	Open	Output voltage decreased. No hazard.	AVR1:decreased
R312	Open	See 83 Page.	
R313	Open	See 83 Page.	
R314	Open	Normal operation.	AVR1:*
R315	Open	Normal operation.	AVR1:*
R317	Open	Normal operation.	AVR1:*
R318	Open	Normal operation.	AVR1:*
R321	Open	Output voltage decreased. No hazard.	AVR1:decreased
R322	Open	No Hazard.	AVR1:0
R323	Open	Normal operation.	AVR1:*
R324	Open	Output voltage decreased. No hazard.	AVR1:decreased
R325	Open	Normal operation.	AVR1:*
R326	Open	Normal operation.	AVR1:*
R327	Open	Normal operation.	AVR1:*
R332	Open	Normal operation.	AVR1:*
R333	Open	Normal operation.	AVR1:*
R334	Open	Normal operation.	AVR1:*
R335	Open	Normal operation.	AVR1:*
R336	Open	Normal operation.	AVR1:*
R337	Open	Normal operation.	AVR1:*
R339	Open	Normal operation.	AVR1:*
R340	Open	Normal operation.	AVR1:*
R341	Open	Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
R342	Open	Normal operation.	AVR1:*
R343	Open	Output voltage decreased. No hazard.	AVR1:decreased
R344	Open	Normal operation.	AVR1:*
R345	Open	Normal operation.	AVR1:*
R346	Open	Normal operation.	AVR1:*
R347	Open	Normal operation.	AVR1:*
R348	Open	Normal operation.	AVR1:*
R349	Open	Normal operation.	AVR1:*
R350	Open	Normal operation.	AVR1:*
R351	Open	Normal operation.	AVR1:*
R352	Open	Normal operation.	AVR1:*
R353	Open	Output voltage decreased. No hazard.	AVR1:decreased
R354	Open	Normal operation.	AVR1:*
R355	Open	Output voltage decreased. No hazard.	AVR1:decreased
R356	Open	Normal operation.	AVR1:*
R357	Open	No Hazard.	AVR1:0
R358	Open	No Hazard.	AVR1:0
R359	Open	Normal operation.	AVR1:*
R360	Open	Normal operation.	AVR1:*
R362	Open	Normal operation.	AVR1:*
R364	Open	No Hazard.	AVR1:0
R365	Open	No Hazard.	AVR1:0
R367	Open	Normal operation.	AVR1:*
R368	Open	Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
R369	Open	Normal operation.	AVR1:*
R371	Open	Normal operation.	AVR1:*
R372	Open	Normal operation.	AVR1:*
R373	Open	Normal operation.	AVR1:*
R375	Open	Output voltage decreased. No hazard.	AVR1:decreased
R376	Open	Normal operation.	AVR1:*
R377	Open	Output voltage decreased. No hazard.	AVR1:decreased
R378	Open	Normal operation.	AVR1:*
R379	Open	Normal operation.	AVR1:*
R381	Open	See 83 Page.	
R382	Open	Normal operation.	AVR1:*
R383	Open	See 83 Page.	
R384	Open	Normal operation.	AVR1:*
R385	Open	See 84 Page.	
R386	Open	Normal operation.	AVR1:*
R387	Open	See 84 Page.	
R388	Open	Normal operation.	AVR1:*
R391	Open	See 84 Page.	
R392	Open	See 84 Page.	
R393	Open	See 84 Page.	
R394	Open	See 84 Page.	
R395	Open	See 84 Page.	
R396	Open	See 84 Page.	
R397	Open	Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
R398	Open	Normal operation.	AVR1:*
R401	Open	No Hazard.	AVR1:0
R402	Open	Normal operation.	AVR1:*
R403	Open	Normal operation.	AVR1:*
R404	Open	Normal operation.	AVR1:*
R405	Open	Normal operation.	AVR1:*
R406	Open	No Hazard.	AVR1:0
R407	Open	No Hazard.	AVR1:0
R408	Open	No Hazard.	AVR1:0
R409	Open	No Hazard.	AVR1:0
R410	Open	No Hazard.	AVR1:0
R411	Open	Normal operation.	AVR1:*
R412	Open	Normal operation.	AVR1:*
R421	Open	Normal operation.	AVR1:*
R422	Open	No Hazard.	AVR1:0
R423	Open	Normal operation.	AVR1:*
R424	Open	Normal operation.	AVR1:*
R511	Open	See 84 Page.	
R512	Open	See 84 Page.	
R513	Open	See 84 Page.	
R514	Open	See 84 Page.	
R521	Open	Normal operation.	AVR1:*
R522	Open	Normal operation.	AVR1:*
R523	Open	Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
R524	Open	Normal operation.	AVR1:*
R531	Open	Normal operation.	AVR1:*
R532	Open	Normal operation.	AVR1:*
R533	Open	Normal operation.	AVR1:*
R534	Open	Normal operation.	AVR1:*
R541	Open	See 84 Page.	
R542	Open	See 84 Page.	
R543	Open	See 84 Page.	
R544	Open	See 84 Page.	
R551	Open	Normal operation.	AVR1:*
R552	Open	Normal operation.	AVR1:*
R553	Open	Normal operation.	AVR1:*
R554	Open	Normal operation.	AVR1:*
R561	Open	Normal operation.	AVR1:*
R562	Open	Normal operation.	AVR1:*
R563	Open	Normal operation.	AVR1:*
R564	Open	Normal operation.	AVR1:*
R601	Open	Normal operation.	AVR1:*
R603	Open	Normal operation.	AVR1:*
R604	Open	No Hazard.	AVR1:0
R605	Open	Normal operation.	AVR1:*
R611	Open	Normal operation.	AVR1:*
R612	Open	Normal operation.	AVR1:*
R613	Open	Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
R614	Open	Output voltage decreased. No hazard.	AVR1:decreased
R615	Open	No Hazard.	AVR1:0
R616	Open	Normal operation.	AVR1:*
R617	Open	No Hazard.	AVR1:0
R618	Open	No Hazard.	AVR1:0
R619	Open	No Hazard.	AVR1:0
R620	Open	No Hazard.	AVR1:0
R621	Open	Normal operation.	AVR1:*
R622	Open	Normal operation.	AVR1:*
R623	Open	Normal operation.	AVR1:*
R624	Open	Output voltage decreased. No hazard.	AVR1:decreased
R625	Open	No Hazard.	AVR1:0
R626	Open	Normal operation.	AVR1:*
R627	Open	No Hazard.	AVR1:0
R628	Open	No Hazard.	AVR1:0
R629	Open	No Hazard.	AVR1:0
R630	Open	No Hazard.	AVR1:0
R631	Open	No Hazard.	AVR1:0
R632	Open	Normal operation.	AVR1:*
R633	Open	No Hazard.	AVR1:0
R634	Open	Normal operation.	AVR1:*
R635	Open	Normal operation.	AVR1:*
R636	Open	Normal operation.	AVR1:*
R637	Open	No Hazard.	AVR1:0

F M E A

Component	Mode	Comment	Output Voltage (V)
R638	Open	Normal operation.	AVR1:*
R639	Open	No Hazard.	AVR1:0
R651	Open	Normal operation.	AVR1:*
R652	Open	Normal operation.	AVR1:*
R653	Open	Normal operation.	AVR1:*
R654	Open	Normal operation.	AVR1:*
R655	Open	Normal operation.	AVR1:*
R661	Open	Normal operation.	AVR1:*
R662	Open	Normal operation.	AVR1:*
R663	Open	Normal operation.	AVR1:*
R664	Open	Normal operation.	AVR1:*
R665	Open	Normal operation.	AVR1:*
R667	Open	Normal operation.	AVR1:*
R668	Open	Normal operation.	AVR1:*
R669	Open	Normal operation.	AVR1:*
R670	Open	Normal operation.	AVR1:*
R671	Open	Normal operation.	AVR1:*
R691	Open	Normal operation.	AVR1:*
R692	Open	Normal operation.	AVR1:*
R693	Open	Normal operation.	AVR1:*
R701	Open	Normal operation.	AVR1:*
R703	Open	Normal operation.	AVR1:*
R704	Open	Normal operation.	AVR1:*
R705	Open	Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
R706	Open	Normal operation.	AVR1:*
R707	Open	No Hazard.	AVR1:0
R708	Open	No Hazard.	AVR1:0
R709	Open	Normal operation.	AVR1:*
R710	Open	No Hazard.	AVR1:0
R711	Open	No Hazard.	AVR1:0
R712	Open	Normal operation.	AVR1:*
R713	Open	Normal operation.	AVR1:*
R714	Open	Normal operation.	AVR1:*
R715	Open	Normal operation.	AVR1:*
R716	Open	No Hazard.	AVR1:0
R721	Open	No Hazard.	AVR1:0
R722	Open	Normal operation.	AVR1:*
R723	Open	Normal operation.	AVR1:*
R724	Open	Output voltage decreased. No hazard.	AVR1:decreased
R726	Open	No Hazard.	AVR1:0
R727	Open	Normal operation.	AVR1:*
R728	Open	Normal operation.	AVR1:*
R729	Open	Normal operation.	AVR1:*
R730	Open	Output voltage decreased. No hazard.	AVR1:decreased
R731	Open	No Hazard.	AVR1:0
R732	Open	Output voltage decreased. No hazard.	AVR1:decreased
R733	Open	Output voltage decreased. No hazard.	AVR1:decreased
R734	Open	No Hazard.	AVR1:0

F M E A

Component	Mode	Comment	Output Voltage (V)
R735	Open	Output voltage decreased. No hazard.	AVR1:decreased
R736	Open	Normal operation.	AVR1:*
R737	Open	Output voltage decreased. No hazard.	AVR1:decreased
R738	Open	Output voltage decreased. No hazard.	AVR1:decreased
R739	Open	Normal operation.	AVR1:*
R740	Open	Normal operation.	AVR1:*
R741	Open	See 84 Page.	
R742	Open	See 84 Page.	
R743	Open	No Hazard.	AVR1:0
R744	Open	No Hazard.	AVR1:0
R749	Open	No Hazard.	AVR1:0
R750	Open	Normal operation.	AVR1:*
R751	Open	Normal operation.	AVR1:*
R752	Open	No Hazard.	AVR1:0
R753	Open	Normal operation.	AVR1:*
R754	Open	Normal operation.	AVR1:*
R755	Open	Normal operation.	AVR1:*
R756	Open	Normal operation.	AVR1:*
R757	Open	No Hazard.	AVR1:0
R759	Open	Output voltage decreased. No hazard.	AVR1:decreased
R760	Open	Output voltage decreased. No hazard.	AVR1:decreased
R761	Open	Output voltage increased. No hazard.	AVR1:increased(130%)
R762	Open	Normal operation.	AVR1:*
R763	Open	Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
R764	Open	Normal operation.	AVR1:*
R765	Open	Normal operation.	AVR1:*
R766	Open	Normal operation.	AVR1:*
R767	Open	Normal operation.	AVR1:*
R768	Open	Normal operation.	AVR1:*
R771	Open	Output voltage decreased. No hazard.	AVR1:decreased
R772	Open	Output voltage decreased. No hazard.	AVR1:decreased
R773	Open	Normal operation.	AVR1:*
R774	Open	Normal operation.	AVR1:*
R781	Open	No Hazard.	AVR1:0
R782	Open	No Hazard.	AVR1:0
R783	Open	Normal operation.	AVR1:*
R784	Open	No Hazard.	AVR1:0
R785	Open	No Hazard.	AVR1:0
R786	Open	No Hazard.	AVR1:0
R787	Open	No Hazard.	AVR1:0
R788	Open	No Hazard.	AVR1:0
R789	Open	No Hazard.	AVR1:0
R790	Open	Normal operation.	AVR1:*
R791	Open	Normal operation.	AVR1:*
R792	Open	Normal operation.	AVR1:*
R793	Open	Normal operation.	AVR1:*
R795	Open	Normal operation.	AVR1:*
R796	Open	Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
R799	Open	Normal operation.	AVR1:*
R801	Open	No Hazard.	AVR1:0
R802	Open	Normal operation.	AVR1:*
R803	Open	No Hazard.	AVR1:0
R804	Open	No Hazard.	AVR1:0
R813	Open	Normal operation.	AVR1:*
R814	Open	Normal operation.	AVR1:*
R815	Open	Normal operation.	AVR1:*
R821	Open	Normal operation.	AVR1:*
R822	Open	Normal operation.	AVR1:*
R823	Open	Normal operation.	AVR1:*
R831	Open	Normal operation.	AVR1:*
R832	Open	Normal operation.	AVR1:*
R901	Open	Normal operation.	AVR1:*
R902	Open	Normal operation.	AVR1:*
R903	Open	Normal operation.	AVR1:*
R904	Open	Normal operation.	AVR1:*
R905	Open	No Hazard.	AVR1:0
R906	Open	Normal operation.	AVR1:*
R907	Open	Normal operation.	AVR1:*
R908	Open	Normal operation.	AVR1:*
R909	Open	Normal operation.	AVR1:*
R910	Open	Normal operation.	AVR1:*
R911	Open	Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
R912	Open	Normal operation.	AVR1:*
R913	Open	Normal operation.	AVR1:*
R914	Open	Normal operation.	AVR1:*
R915	Open	Normal operation.	AVR1:*
R916	Open	Normal operation.	AVR1:*
R921	Open	Normal operation.	AVR1:*
R922	Open	Normal operation.	AVR1:*
R923	Open	Normal operation.	AVR1:*
R924	Open	Normal operation.	AVR1:*
R925	Open	Normal operation.	AVR1:*
R926	Open	Normal operation.	AVR1:*
R927	Open	Normal operation.	AVR1:*
R931	Open	Normal operation.	AVR1:*
R932	Open	Normal operation.	AVR1:*
R941	Open	Normal operation.	AVR1:*
R942	Open	Normal operation.	AVR1:*
R943	Open	Normal operation.	AVR1:*
R944	Open	Normal operation.	AVR1:*
R951	Open	Normal operation.	AVR1:*
R952	Open	Normal operation.	AVR1:*
R953	Open	Normal operation.	AVR1:*
R954	Open	Normal operation.	AVR1:*
R955	Open	Normal operation.	AVR1:*
R956	Open	Normal operation.	AVR1:*

F M E A

Component	Mode		Comment	Output Voltage (V)
R971	Open		Normal operation.	AVR1:*
SS101	Open	1	No Hazard.	AVR1:0
		2	No Hazard.	AVR1:0
		3	No Hazard.	AVR1:0
		4	No Hazard.	AVR1:0
	Short	1-2	See 84 Page.	
		2-3	See 84 Page.	
		3-4	See 84 Page.	
	Open	1	No Hazard.	AVR1:0
		2	No Hazard.	AVR1:0
		3	No Hazard.	AVR1:0
		4	No Hazard.	AVR1:0
		5	No Hazard.	AVR1:0
		6	No Hazard.	AVR1:0
		7	No Hazard.	AVR1:0
		8	No Hazard.	AVR1:0
		9	No Hazard.	AVR1:0
		10	No Hazard.	AVR1:0
T401	Short	1-2	No Hazard.	AVR1:0
		2-3	No Hazard.	AVR1:0
		3-4	No Hazard.	AVR1:0
		5-6	No Hazard.	AVR1:0
		6-7	No Hazard.	AVR1:0
		7-8	No Hazard.	AVR1:0

F M E A

Component	Mode		Comment	Output Voltage (V)
T401	Short	8-9	No Hazard.	AVR1:0
		9-10	No Hazard.	AVR1:0
T501	Open	1	No Hazard.	AVR1:0
		2	No Hazard.	AVR1:0
		3	See 84 Page.	
		4	See 84 Page.	
		5	See 84 Page.	
		6	See 85 Page.	
		7	See 85 Page.	
		8	See 85 Page.	
		9	See 85 Page.	
		10	See 85 Page.	
		11	See 85 Page.	
		12	See 85 Page.	
		13	See 85 Page.	
		14	See 85 Page.	
	Short	1-2	See 85 Page.	
		3-4	Output voltage decreased. No hazard.	AVR1:decreased
		4-5	Output voltage decreased. No hazard.	AVR1:decreased
		6-7	Output voltage decreased. No hazard.	AVR1:decreased
		7-8	Output voltage decreased. No hazard.	AVR1:decreased
		9-10	Output voltage decreased. No hazard.	AVR1:decreased
		10-11	Output voltage decreased. No hazard.	AVR1:decreased
		12-13	Output voltage decreased. No hazard.	AVR1:decreased

F M E A

Component	Mode		Comment	Output Voltage (V)
T501	Short	13-14	Output voltage decreased. No hazard.	AVR1:decreased
T901	Open	1	Normal operation.	AVR1:*
		2	Normal operation.	AVR1:*
		3	Normal operation.	AVR1:*
		4	Normal operation.	AVR1:*
		5	Normal operation.	AVR1:*
		6	Normal operation.	AVR1:*
	Short	1-2	No Hazard.	AVR1:0
		2-3	Normal operation.	AVR1:*
		3-4	Normal operation.	AVR1:*
		4-5	Normal operation.	AVR1:*
		5-6	Normal operation.	AVR1:*
TH201	Open		Normal operation.	AVR1:*
	Short		Output voltage decreased. No hazard.	AVR1:decreased
TR101	Open	D	See 85 Page.	
		S	See 85 Page.	
		G	See 85 Page.	
	Short	D-S	See 85 Page.	
		S-G	See 85 Page.	
		G-D	See 85 Page.	
TR103	Open	D	See 85 Page.	
		S	See 85 Page.	
		G	See 85 Page.	
	Short	D-S	See 85 Page.	

F M E A

Component	Mode		Comment	Output Voltage (V)
TR103	Short	S-G	See 85 Page.	
		G-D	See 85 Page.	
TR151	Open	D	Normal operation.	AVR1:*
		S	Normal operation.	AVR1:*
		G	Normal operation.	AVR1:*
	Short	D-S	Normal operation.	AVR1:*
		S-G	Normal operation.	AVR1:*
		G-D	Normal operation.	AVR1:*
TR152	Open	D	Normal operation.	AVR1:*
		S	Normal operation.	AVR1:*
		G	Normal operation.	AVR1:*
	Short	D-S	Normal operation.	AVR1:*
		S-G	Normal operation.	AVR1:*
		G-D	Normal operation.	AVR1:*
TR153	Open	D	Normal operation.	AVR1:*
		S	Normal operation.	AVR1:*
		G	No Hazard.	AVR1:0
	Short	D-S	No Hazard.	AVR1:0
		S-G	Normal operation.	AVR1:*
		G-D	No Hazard.	AVR1:0
TR180	Open	D	No Hazard.	AVR1:0
		S	No Hazard.	AVR1:0
		G	No Hazard.	AVR1:0
	Short	D-S	Normal operation.	AVR1:*

F M E A

Component	Mode		Comment	Output Voltage (V)
TR180	Short	S-G	No Hazard.	AVR1:0
		G-D	Normal operation.	AVR1:*
TR181	Open	1 (1)	Normal operation.	AVR1:*
		1 (2)	Normal operation.	AVR1:*
		2 (3)	No Hazard.	AVR1:0
		2 (4)	No Hazard.	AVR1:0
		2 (5)	No Hazard.	AVR1:0
		1 (6)	Normal operation.	AVR1:*
	Short	1-1 (1-2)	Normal operation.	AVR1:*
		1-2 (2-3)	Normal operation.	AVR1:*
		2-2 (4-5)	No Hazard.	AVR1:0
		2-1 (5-6)	Normal operation.	AVR1:*
TR221	Open	D	Normal operation.	AVR1:*
		S	Normal operation.	AVR1:*
		G	Normal operation.	AVR1:*
	Short	D-S	Normal operation.	AVR1:*
		S-G	Normal operation.	AVR1:*
		G-D	Normal operation.	AVR1:*
TR251	Open	D	Normal operation.	AVR1:*
		S	Normal operation.	AVR1:*
		G	Normal operation.	AVR1:*
	Short	D-S	Normal operation.	AVR1:*
		S-G	Normal operation.	AVR1:*
		G-D	Normal operation.	AVR1:*

F M E A

Component	Mode		Comment	Output Voltage (V)
TR252	Open	D	No Hazard.	AVR1:0
		S	No Hazard.	AVR1:0
		G	No Hazard.	AVR1:0
	Short	D-S	No Hazard.	AVR1:0
		S-G	No Hazard.	AVR1:0
		G-D	No Hazard.	AVR1:0
TR301	Open	D	See 85 Page.	
		S	See 85 Page.	
		G	See 86 Page.	
	Short	D-S	See 86 Page.	
		S-G	See 86 Page.	
		G-D	See 86 Page.	
TR302	Open	D	See 86 Page.	
		S	See 86 Page.	
		G	See 86 Page.	
	Short	D-S	See 86 Page.	
		S-G	See 86 Page.	
		G-D	See 86 Page.	
TR303	Open	D	Normal operation.	AVR1:*
		S	Normal operation.	AVR1:*
		G	Normal operation.	AVR1:*
	Short	D-S	No Hazard.	AVR1:0
		S-G	Normal operation.	AVR1:*
		G-D	No Hazard.	AVR1:0

F M E A

Component	Mode		Comment	Output Voltage (V)
TR304	Open	C	Normal operation.	AVR1:*
		E	Normal operation.	AVR1:*
		B	Normal operation.	AVR1:*
	Short	C-E	Normal operation.	AVR1:*
		E-B	Normal operation.	AVR1:*
		B-C	Normal operation.	AVR1:*
TR305	Open	C	Normal operation.	AVR1:*
		E	Normal operation.	AVR1:*
		B	Normal operation.	AVR1:*
	Short	C-E	No Hazard.	AVR1:*
		E-B	Normal operation.	AVR1:*
		B-C	No Hazard.	AVR1:*
TR311	Open	D	See 86 Page.	
		S	See 86 Page.	
		G	See 86 Page.	
	Short	D-S	See 86 Page.	
		S-G	See 86 Page.	
		G-D	See 86 Page.	
TR312	Open	D	See 86 Page.	
		S	See 86 Page.	
		G	See 86 Page.	
	Short	D-S	See 86 Page.	
		S-G	See 86 Page.	
		G-D	See 86 Page.	

F M E A

Component	Mode		Comment	Output Voltage (V)
TR313	Open	D	See 86 Page.	
		S	See 86 Page.	
		G	See 87 Page.	
	Short	D-S	See 87 Page.	
		S-G	See 87 Page.	
		G-D	See 87 Page.	
TR314	Open	D	See 87 Page.	
		S	See 87 Page.	
		G	See 87 Page.	
	Short	D-S	See 87 Page.	
		S-G	See 87 Page.	
		G-D	See 87 Page.	
TR331	Open	1 (1)	Normal operation.	AVR1:*
		1 (2)	Normal operation.	AVR1:*
		2 (3)	Normal operation.	AVR1:*
		2 (4)	Normal operation.	AVR1:*
		2 (5)	Normal operation.	AVR1:*
		1 (6)	Normal operation.	AVR1:*
	Short	1-1 (1-2)	Normal operation.	AVR1:*
		1-2 (2-3)	Normal operation.	AVR1:*
		2-2 (4-5)	Normal operation.	AVR1:*
		2-1 (5-6)	Normal operation.	AVR1:*
TR332	Open	C	Normal operation.	AVR1:*
		E	Normal operation.	AVR1:*

F M E A

Component	Mode		Comment	Output Voltage (V)
TR332	Open	B	Normal operation.	AVR1:*
	Short	C-E	Output voltage decreased. No hazard.	AVR1:decreased
		E-B	Normal operation.	AVR1:*
		B-C	Output voltage decreased. No hazard.	AVR1:decreased
TR341	Open	C	Normal operation.	AVR1:*
		E	Normal operation.	AVR1:*
		B	Normal operation.	AVR1:*
	Short	C-E	Output voltage decreased. No hazard.	AVR1:decreased
		E-B	Normal operation.	AVR1:*
		B-C	Output voltage decreased. No hazard.	AVR1:decreased
TR351	Open	1 (1)	Normal operation.	AVR1:*
		1 (2)	Normal operation.	AVR1:*
		2 (3)	Normal operation.	AVR1:*
		2 (4)	Normal operation.	AVR1:*
		2 (5)	Normal operation.	AVR1:*
		1 (6)	Normal operation.	AVR1:*
	Short	1-1 (1-2)	Normal operation.	AVR1:*
		1-2 (2-3)	Normal operation.	AVR1:*
		2-2 (4-5)	Normal operation.	AVR1:*
		2-1 (5-6)	Normal operation.	AVR1:*
TR352	Open	D	Output voltage decreased. No hazard.	AVR1:decreased
		S	Output voltage decreased. No hazard.	AVR1:decreased
		G	Output voltage decreased. No hazard.	AVR1:decreased
	Short	D-S	Output voltage decreased. No hazard.	AVR1:decreased

F M E A

Component	Mode		Comment	Output Voltage (V)
TR352	Short	S-G	Output voltage decreased. No hazard.	AVR1:decreased
		G-D	Output voltage decreased. No hazard.	AVR1:decreased
TR401	Open	1 (1)	No Hazard.	AVR1:0
		1 (2)	No Hazard.	AVR1:0
		2 (3)	Normal operation.	AVR1:*
		2 (4)	Normal operation.	AVR1:*
		2 (5)	No Hazard.	AVR1:0
		1 (6)	No Hazard.	AVR1:0
	Short	1-1 (1-2)	No Hazard.	AVR1:0
		1-2 (2-3)	No Hazard.	AVR1:0
		2-2 (4-5)	Normal operation.	AVR1:*
		2-1 (5-6)	Normal operation.	AVR1:*
TR511	Open	D	See 87 Page.	
		S	See 87 Page.	
		G	See 87 Page.	
	Short	D-S	Output voltage decreased. No hazard.	AVR1:decreased
		S-G	See 87 Page.	
		G-D	Output voltage decreased. No hazard.	AVR1:decreased
TR512	Open	D	See 87 Page.	
		S	See 87 Page.	
		G	See 87 Page.	
	Short	D-S	Output voltage decreased. No hazard.	AVR1:decreased
		S-G	See 87 Page.	
		G-D	Output voltage decreased. No hazard.	AVR1:decreased

F M E A

Component	Mode		Comment	Output Voltage (V)
TR513	Open	D	See 87 Page.	
		S	See 87 Page.	
		G	See 87 Page.	
	Short	D-S	Output voltage decreased. No hazard.	AVR1:decreased
		S-G	See 87 Page.	
		G-D	Output voltage decreased. No hazard.	AVR1:decreased
TR514	Open	D	See 87 Page.	
		S	See 87 Page.	
		G	See 88 Page.	
	Short	D-S	Output voltage decreased. No hazard.	AVR1:decreased
		S-G	See 88 Page.	
		G-D	Output voltage decreased. No hazard.	AVR1:decreased
TR521	Open	D	See 88 Page.	
		S	See 88 Page.	
		G	See 88 Page.	
	Short	D-S	Output voltage decreased. No hazard.	AVR1:decreased
		S-G	See 88 Page.	
		G-D	Output voltage decreased. No hazard.	AVR1:decreased
TR522	Open	D	See 88 Page.	
		S	See 88 Page.	
		G	See 88 Page.	
	Short	D-S	Output voltage decreased. No hazard.	AVR1:decreased
		S-G	See 88 Page.	
		G-D	Output voltage decreased. No hazard.	AVR1:decreased

F M E A

Component	Mode		Comment	Output Voltage (V)
TR523	Open	D	See 88 Page.	
		S	See 88 Page.	
		G	See 88 Page.	
	Short	D-S	Output voltage decreased. No hazard.	AVR1:decreased
		S-G	See 88 Page.	
		G-D	Output voltage decreased. No hazard.	AVR1:decreased
TR524	Open	D	See 88 Page.	
		S	See 88 Page.	
		G	See 88 Page.	
	Short	D-S	Output voltage decreased. No hazard.	AVR1:decreased
		S-G	See 88 Page.	
		G-D	Output voltage decreased. No hazard.	AVR1:decreased
TR601	Open	C	Normal operation.	AVR1:*
		E	No Hazard.	AVR1:0
		B	No Hazard.	AVR1:0
	Short	C-E	Normal operation.	AVR1:*
		E-B	No Hazard.	AVR1:0
		B-C	No Hazard.	AVR1:0
TR602	Open	C	No Hazard.	AVR1:0
		E	No Hazard.	AVR1:0
		B	No Hazard.	AVR1:0
	Short	C-E	No Hazard.	AVR1:0
		E-B	No Hazard.	AVR1:0
		B-C	No Hazard.	AVR1:0

F M E A

Component	Mode		Comment	Output Voltage (V)
TR611	Open	S (1)	Output voltage decreased. No hazard.	AVR1:decreased
		G (2)	Output voltage decreased. No hazard.	AVR1:decreased
		D (3)	No Hazard.	AVR1:0
		S (4)	No Hazard.	AVR1:0
		G (5)	No Hazard.	AVR1:0
		D (6)	Output voltage decreased. No hazard.	AVR1:decreased
	Short	S-G (1-2)	Output voltage decreased. No hazard.	AVR1:decreased
		G-D (2-3)	No Hazard.	AVR1:0
		D-S (3-4)	No Hazard.	AVR1:0
		S-G (4-5)	No Hazard.	AVR1:0
		G-D (5-6)	No Hazard.	AVR1:0
TR612	Open	C	No Hazard.	AVR1:0
		E	No Hazard.	AVR1:0
		B	No Hazard.	AVR1:0
	Short	C-E	Normal operation.	AVR1:*
		E-B	No Hazard.	AVR1:0
		B-C	Normal operation.	AVR1:*
TR621	Open	S (1)	Output voltage decreased. No hazard.	AVR1:decreased
		G (2)	Output voltage decreased. No hazard.	AVR1:decreased
		D (3)	No Hazard.	AVR1:0
		S (4)	No Hazard.	AVR1:0
		G (5)	No Hazard.	AVR1:0
		D (6)	Output voltage decreased. No hazard.	AVR1:decreased
	Short	S-G (1-2)	Output voltage decreased. No hazard.	AVR1:decreased

F M E A

Component	Mode		Comment	Output Voltage (V)
TR621	Short	G-D (2-3)	No Hazard.	AVR1:0
		D-S (3-4)	No Hazard.	AVR1:0
		S-G (4-5)	No Hazard.	AVR1:0
		G-D (5-6)	No Hazard.	AVR1:0
TR622	Open	C	No Hazard.	AVR1:0
		E	No Hazard.	AVR1:0
		B	No Hazard.	AVR1:0
	Short	C-E	Normal operation.	AVR1:*
		E-B	No Hazard.	AVR1:0
		B-C	Normal operation.	AVR1:*
TR631	Open	E (1)	Normal operation.	AVR1:*
		B (2)	Normal operation.	AVR1:*
		C (3)	Normal operation.	AVR1:*
		E (4)	Normal operation.	AVR1:*
		B (5)	Normal operation.	AVR1:*
		C (6)	Normal operation.	AVR1:*
	Short	E-B (1-2)	Normal operation.	AVR1:*
		B-C (2-3)	No Hazard.	AVR1:0
		E-B (4-5)	Normal operation.	AVR1:*
		B-C (5-6)	No Hazard.	AVR1:0
TR691	Open	C	Normal operation.	AVR1:*
		E	Normal operation.	AVR1:*
		B	Normal operation.	AVR1:*
	Short	C-E	Normal operation.	AVR1:*

F M E A

Component	Mode		Comment	Output Voltage (V)
TR691	Short	E-B	Normal operation.	AVR1:*
		B-C	Normal operation.	AVR1:*
TR701	Open	D	Normal operation.	AVR1:*
		S	Normal operation.	AVR1:*
		G	Normal operation.	AVR1:*
	Short	D-S	Normal operation.	AVR1:*
		S-G	Normal operation.	AVR1:*
		G-D	Normal operation.	AVR1:*
TR751	Open	C	Normal operation.	AVR1:*
		E	Normal operation.	AVR1:*
		B	Normal operation.	AVR1:*
	Short	C-E	No Hazard.	AVR1:0
		E-B	Normal operation.	AVR1:*
		B-C	No Hazard.	AVR1:0
TR761	Open	1 (1)	Normal operation.	AVR1:*
		1 (2)	Normal operation.	AVR1:*
		2 (3)	Normal operation.	AVR1:*
		2 (4)	Normal operation.	AVR1:*
		2 (5)	Normal operation.	AVR1:*
		1 (6)	Normal operation.	AVR1:*
	Short	1-1 (1-2)	Normal operation.	AVR1:*
		1-2 (2-3)	Normal operation.	AVR1:*
		2-2 (4-5)	Normal operation.	AVR1:*
		2-1 (5-6)	Normal operation.	AVR1:*

F M E A

Component	Mode		Comment	Output Voltage (V)
TR771	Open	D	Normal operation.	AVR1:*
		S	Normal operation.	AVR1:*
		G	Normal operation.	AVR1:*
	Short	D-S	Normal operation.	AVR1:*
		S-G	Normal operation.	AVR1:*
		G-D	Normal operation.	AVR1:*
TR781	Open	1 (1)	No Hazard.	AVR1:0
		1 (2)	No Hazard.	AVR1:0
		2 (3)	No Hazard.	AVR1:0
		2 (4)	No Hazard.	AVR1:0
		2 (5)	No Hazard.	AVR1:0
		1 (6)	No Hazard.	AVR1:0
	Short	1-1 (1-2)	No Hazard.	AVR1:0
		1-2 (2-3)	No Hazard.	AVR1:0
		2-2 (4-5)	No Hazard.	AVR1:0
		2-1 (5-6)	No Hazard.	AVR1:0
TR782	Open	D	No Hazard.	AVR1:0
		S	No Hazard.	AVR1:0
		G	No Hazard.	AVR1:0
	Short	D-S	No Hazard.	AVR1:0
		S-G	No Hazard.	AVR1:0
		G-D	No Hazard.	AVR1:0
TR791	Open	D	Normal operation.	AVR1:*
		S	Normal operation.	AVR1:*

F M E A

Component	Mode		Comment	Output Voltage (V)
TR791	Open	G	Normal operation.	AVR1:*
	Short	D-S	Normal operation.	AVR1:*
		S-G	Normal operation.	AVR1:*
		G-D	Normal operation.	AVR1:*
TR801	Open	D	No Hazard.	AVR1:0
		S	No Hazard.	AVR1:0
		G	No Hazard.	AVR1:0
	Short	D-S	No Hazard.	AVR1:*
		S-G	No Hazard.	AVR1:0
		G-D	No Hazard.	AVR1:*
TR901	Open	D	Normal operation.	AVR1:*
		S	Normal operation.	AVR1:*
		G	Normal operation.	AVR1:*
	Short	D-S	No Hazard.	AVR1:0
		S-G	Normal operation.	AVR1:*
		G-D	No Hazard.	AVR1:0
TR902	Open	S(1)	No Hazard.	AVR1:0
		G(2)	No Hazard.	AVR1:0
		D(3)	Normal operation.	AVR1:*
		S(4)	Normal operation.	AVR1:*
		G(5)	Normal operation.	AVR1:*
		D(6)	No Hazard.	AVR1:0
	Short	S-G(1-2)	No Hazard.	AVR1:0
		G-D(2-3)	No Hazard.	AVR1:0

F M E A

Component	Mode		Comment	Output Voltage (V)
TR902	Short	S-G (4-5)	Normal operation.	AVR1:*
		G-D (5-6)	Normal operation.	AVR1:*
TR921	Open	D	Normal operation.	AVR1:*
		S	Normal operation.	AVR1:*
		G	Normal operation.	AVR1:*
	Short	D-S	Normal operation.	AVR1:*
		S-G	Normal operation.	AVR1:*
		G-D	Normal operation.	AVR1:*
TR931	Open	D	Normal operation.	AVR1:*
		S	Normal operation.	AVR1:*
		G	Normal operation.	AVR1:*
	Short	D-S	Normal operation.	AVR1:*
		S-G	Normal operation.	AVR1:*
		G-D	Normal operation.	AVR1:*
VR701	Open	brush	No Hazard.	AVR1:0
			No Hazard.	AVR1:0
	Short		Output voltage decreased. No hazard.	AVR1:0
X101	Open	1	No Hazard.	AVR1:0
		2	No Hazard.	AVR1:0
		3	No Hazard.	AVR1:0
		4	No Hazard.	AVR1:0
	Short	1-2	No Hazard.	AVR1:0
		3-4	Normal operation.	AVR1:*
ZD301	Open		Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
ZD301	Short	No Hazard.	AVR1:0
ZD302	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
ZD303	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
ZD321	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
ZD351	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
ZD381	Open	Normal operation.	AVR1:*
	Short	See 88 Page.	
ZD382	Open	Normal operation.	AVR1:*
	Short	See 88 Page.	
ZD421	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
ZD422	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
ZD423	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
ZD601	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
ZD602	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
ZD603	Open	No Hazard.	AVR1:0

F M E A

Component	Mode	Comment	Output Voltage (V)
ZD603	Short	No Hazard.	AVR1:0
ZD604	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
ZD605	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
ZD751	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
ZD761	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
ZD762	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
ZD763	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
ZD801	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
ZD901	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*

ABNORMAL TEST RESULT

Component	Mode	Comment	Output Voltage (V)
C103	Open	No Hazard.	AVR1:*
C151	Short	No Hazard.	AVR1:0
C152	Short	No Hazard.	AVR1:0
C162	Short	No Hazard.	AVR1:0
C341	Short	No Hazard.	AVR1:0
C346	Open	No Hazard.	AVR1:*
C381	Short	No Hazard.	AVR1:0
C382	Short	No Hazard.	AVR1:0
C383	Short	No Hazard.	AVR1:0
C384	Short	No Hazard.	AVR1:0
C392	Open	No Hazard.	AVR1:0
	Short	No Hazard.	AVR1:0
C393	Short	No Hazard.	AVR1:0
C395	Open	No Hazard.	AVR1:0
	Short	No Hazard.	AVR1:0
C396	Short	No Hazard.	AVR1:0
D113	Short	No Hazard.	AVR1:0
D114	Short	No Hazard.	AVR1:0
D115	Short	No Hazard.	AVR1:0
D116	Short	No Hazard.	AVR1:0
D117	Short	No Hazard.	AVR1:0
D118	Short	No Hazard.	AVR1:0
D151	Short	No Hazard.	AVR1:0
D152	Short	No Hazard.	AVR1:0

ABNORMAL TEST RESULT

Component	Mode		Comment	Output Voltage (V)
D301	Short		No Hazard.	AVR1:0
D381	Open		No Hazard.	AVR1:0
D383	Open		No Hazard.	AVR1:0
IC101	Open	1	No Hazard.	AVR1:0
		4	No Hazard.	AVR1:0
		11	No Hazard.	AVR1:0
		14	No Hazard.	AVR1:0
		16	No Hazard.	AVR1:0
	Short	10-11	No Hazard.	AVR1:0
		13-14	No Hazard.	AVR1:0
IC201	Short	28-29	No Hazard.	AVR1:0
IC301	Short	7-8	F101, F102 opend, No hazard.	AVR1:0
IC311	Open	4	No Hazard.	AVR1:0
		5	No Hazard.	AVR1:0
		6	No Hazard.	AVR1:0
		7	No Hazard.	AVR1:0
		8	No Hazard.	AVR1:0
	Short	2-3	No Hazard.	AVR1:0
		3-4	No Hazard.	AVR1:0
		6-7	No Hazard.	AVR1:0
		7-8	No Hazard.	AVR1:0
IC312	Open	4	No Hazard.	AVR1:0
		5	No Hazard.	AVR1:0
		6	No Hazard.	AVR1:0

ABNORMAL TEST RESULT

Component	Mode		Comment	Output Voltage (V)
IC312	Open	7	No Hazard.	AVR1:0
		8	No Hazard.	AVR1:0
	Short	2-3	No Hazard.	AVR1:0
		3-4	No Hazard.	AVR1:0
		6-7	No Hazard.	AVR1:0
		7-8	No Hazard.	AVR1:0
IC401	Short	D-S	No Hazard.	AVR1:0
L103	Open	1	No Hazard.	AVR1:0
		2	No Hazard.	AVR1:0
		3	No Hazard.	AVR1:0
		4	No Hazard.	AVR1:0
		5	No Hazard.	AVR1:0
		6	No Hazard.	AVR1:0
		7	No Hazard.	AVR1:0
	Short	5-6	No Hazard.	AVR1:0
		6-7	No Hazard.	AVR1:0
R122	Open		No Hazard.	AVR1:0
R127	Open		No Hazard.	AVR1:0
R151	Open		No Hazard.	AVR1:0
R152	Open		No Hazard.	AVR1:0
R312	Open		Normal operation.	AVR1:*
R313	Open		Normal operation.	AVR1:*
R381	Open		No Hazard.	AVR1:0
R383	Open		No Hazard.	AVR1:0

ABNORMAL TEST RESULT

Component	Mode		Comment	Output Voltage (V)
R385	Open		No Hazard.	AVR1:0
R387	Open		No Hazard.	AVR1:0
R391	Open		No Hazard.	AVR1:0
R392	Open		No Hazard.	AVR1:0
R393	Open		No Hazard.	AVR1:0
R394	Open		No Hazard.	AVR1:0
R395	Open		No Hazard.	AVR1:0
R396	Open		No Hazard.	AVR1:0
R511	Open		Normal operation.	AVR1:*
R512	Open		Normal operation.	AVR1:*
R513	Open		Normal operation.	AVR1:*
R514	Open		Normal operation.	AVR1:*
R541	Open		Normal operation.	AVR1:*
R542	Open		Normal operation.	AVR1:*
R543	Open		Normal operation.	AVR1:*
R544	Open		Normal operation.	AVR1:*
R741	Open		No Hazard.	AVR1:137%
R742	Open		No Hazard.	AVR1:137%
SS101	Short	1-2	F101, F102 opend, No hazard.	AVR1:0
		2-3	F101, F102 opend, No hazard.	AVR1:0
		3-4	F101, F102 opend, No hazard.	AVR1:0
T501	Open	3	Normal operation.	AVR1:*
		4	Normal operation.	AVR1:*
		5	Normal operation.	AVR1:*

ABNORMAL TEST RESULT

Component	Mode		Comment	Output Voltage (V)
T501	Open	6	Normal operation.	AVR1:*
		7	Normal operation.	AVR1:*
		8	Normal operation.	AVR1:*
		9	Normal operation.	AVR1:*
		10	Normal operation.	AVR1:*
		11	Normal operation.	AVR1:*
		12	Normal operation.	AVR1:*
		13	Normal operation.	AVR1:*
		14	Normal operation.	AVR1:*
	Short	1-2	No Hazard.	AVR1:0
TR101	Open	D	No Hazard.	AVR1:0
		S	No Hazard.	AVR1:0
		G	No Hazard.	AVR1:0
	Short	D-S	F101, F102 opend, No hazard.	AVR1:0
		S-G	No Hazard.	AVR1:0
		G-D	F101, F102 opend, No hazard.	AVR1:0
TR103	Open	D	No Hazard.	AVR1:0
		S	No Hazard.	AVR1:0
		G	No Hazard.	AVR1:0
	Short	D-S	F101, F102 opend, No hazard.	AVR1:0
		S-G	No Hazard.	AVR1:0
		G-D	F101, F102 opend, No hazard.	AVR1:0
TR301	Open	D	Normal operation.	AVR1:*
		S	Normal operation.	AVR1:*

ABNORMAL TEST RESULT

Component	Mode		Comment	Output Voltage (V)
TR301	Open	G	Normal operation.	AVR1:*
	Short	D-S	F101, F102 opend, No hazard.	AVR1:0
		S-G	Normal operation.	AVR1:*
		G-D	F101, F102 opend, No hazard.	AVR1:0
TR302	Open	D	Normal operation.	AVR1:*
		S	Normal operation.	AVR1:*
		G	Normal operation.	AVR1:*
	Short	D-S	F101, F102 opend, No hazard.	AVR1:0
		S-G	Normal operation.	AVR1:*
		G-D	F101, F102 opend, No hazard.	AVR1:0
TR311	Open	D	No Hazard.	AVR1:0
		S	No Hazard.	AVR1:0
		G	No Hazard.	AVR1:0
	Short	D-S	No Hazard.	AVR1:0
		S-G	No Hazard.	AVR1:0
		G-D	No Hazard.	AVR1:0
TR312	Open	D	No Hazard.	AVR1:0
		S	No Hazard.	AVR1:0
		G	No Hazard.	AVR1:0
	Short	D-S	No Hazard.	AVR1:0
		S-G	No Hazard.	AVR1:0
		G-D	No Hazard.	AVR1:0
TR313	Open	D	No Hazard.	AVR1:0
		S	No Hazard.	AVR1:0

ABNORMAL TEST RESULT

Component	Mode		Comment	Output Voltage (V)
TR313	Open	G	No Hazard.	AVR1:0
	Short	D-S	No Hazard.	AVR1:0
		S-G	No Hazard.	AVR1:0
		G-D	No Hazard.	AVR1:0
TR314	Open	D	No Hazard.	AVR1:0
		S	No Hazard.	AVR1:0
		G	No Hazard.	AVR1:0
	Short	D-S	No Hazard.	AVR1:0
		S-G	No Hazard.	AVR1:0
		G-D	No Hazard.	AVR1:0
TR511	Open	D	Normal operation.	AVR1:*
		S	Normal operation.	AVR1:*
		G	Normal operation.	AVR1:*
	Short	S-G	Normal operation.	AVR1:*
TR512	Open	D	Normal operation.	AVR1:*
		S	Normal operation.	AVR1:*
		G	Normal operation.	AVR1:*
	Short	S-G	Normal operation.	AVR1:*
TR513	Open	D	Normal operation.	AVR1:*
		S	Normal operation.	AVR1:*
		G	Normal operation.	AVR1:*
	Short	S-G	Normal operation.	AVR1:*
TR514	Open	D	Normal operation.	AVR1:*
		S	Normal operation.	AVR1:*

ABNORMAL TEST RESULT

Component	Mode		Comment	Output Voltage (V)
TR514	Open	G	Normal operation.	AVR1:*
	Short	S-G	Normal operation.	AVR1:*
TR521	Open	D	Normal operation.	AVR1:*
		S	Normal operation.	AVR1:*
		G	Normal operation.	AVR1:*
	Short	S-G	Normal operation.	AVR1:*
TR522	Open	D	Normal operation.	AVR1:*
		S	Normal operation.	AVR1:*
		G	Normal operation.	AVR1:*
	Short	S-G	Normal operation.	AVR1:*
TR523	Open	D	Normal operation.	AVR1:*
		S	Normal operation.	AVR1:*
		G	Normal operation.	AVR1:*
	Short	S-G	Normal operation.	AVR1:*
TR524	Open	D	Normal operation.	AVR1:*
		S	Normal operation.	AVR1:*
		G	Normal operation.	AVR1:*
	Short	S-G	Normal operation.	AVR1:*
ZD381	Short		No Hazard.	AVR1:0
ZD382	Short		No Hazard.	AVR1:0