

Abnormal Test

Manufacturer : COSEL CO., LTD.

Tested Model [機種名] : YS1005U/YS1005A

Input Ratings [入力定格] :

Voltage AC 100-120 VFrequency 50-60 HzCurrent 0.3 A

Output Ratings [出力定格] :

Voltage 5 V Current 2 A V A V A V A V A V AConducted by [試験担当] : A. OritoReviewed by [照査] : J. Tamm

Abnormal Test [アブノーマル試験]

Rated Input Current: 0.3A, Rated Output Voltage: 5V

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
1	C1	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	R1, R2 Opened
2		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
3	C2	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	R1, R2 Opened
4		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
5	C3	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	R1, R2 Opened
6		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
7	C4	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R1, R2 Opened
8		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
9	C5	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
10		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
11	C6	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
12		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
13	C7	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
14		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
15	C8	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
16		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
17	C9	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
18		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
19	C10	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
20		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
21	C11	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, 19 Opened
22		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.01	5V →0.3V	
23	C12	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
24		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
25	C13	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.01	5V →0V	
26		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
27	C14	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.01	5V →0V	
28		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
29	C15	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.01	5V →0V	
30		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
31	C16	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.01	5V →0V	
32		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
33	C17	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.05	5V →0V	
34		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
35	C18	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.05	5V →0V	
36		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
37	C19	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.05	5V →0V	
38		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
39	C20	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	5V →4.5V	
40		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
41	C21	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
42		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
43	C26	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
44		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
45	C30	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.01	5V →0V	
46		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
47	C31	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.01	5V →0V	
48		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
49	D1	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
50		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
51	D2	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
52		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
53	D3	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
54		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
55	D4	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
56		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
57	D5	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
58		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
59	D8	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.05	5V →2V	
60		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.01	5V →1.5V	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
61	D9	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.05	5V →2V	
62		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.01	5V →1.5V	
63	D30	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
64		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
65	IC1	A-R S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.25	5V →6.8V	
66		A-K S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.05	5V →1.8V	
67		R-K S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.05	5V →3.8V	
68		R OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.25	5V →7V	
69		A OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.25	5V →7V	
70		K OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.25	5V →7V	
71	L1	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
72		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
73	L2	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
74		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
75	PC1	C-E S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.01	5V →1V	
76		C, E OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
77		A-K S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
78		A, K OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
79	R1	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
80	R2	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
81	R3	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
82	R5	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
83	R6	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
84	R7	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
85	R8	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
86	R9	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
87	R10	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
88	R11	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
89	R12	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
90	R13	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
91	R14	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
92	R15	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
93	R16	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
94	R17	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
95	R18	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
96	R19	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
97	R25	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input type="checkbox"/> No [無]	0.05	5V →1.5V	
98	R26	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input type="checkbox"/> No [無]	None	None	
99	R27	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
100	R28	OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
101	SS1	+ OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
102		- OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
103		~ OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
104		+-- S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	R1, R2 Opened
105		+--~ S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	R1, R2 Opened
106		--~ S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	R1, R2 Opened
107	SS2	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
108		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
109	SS3	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
110		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
111	SS4	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
112		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
113	T1	4-5 S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
114		4, 5 OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
115		1-2 S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
116		1, 2 OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
117		2-3 S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
118		2, 3 OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
119		8.9-6.7 S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
120		8.9, 6.7 OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
121	TR1	E OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
122		B OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
123		C OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
124		C-E S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
125		C-B S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
126		B-E S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
127	TR2	E OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
128		B OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
129		C OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
130		C-E S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
131		C-B S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
132		B-E S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
133	TR3	E OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
134		B OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
135		C OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
136		C-E S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	R18, R19 Opened
137		C-B S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
138		B-E S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
139	ZD1	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.05	5V →3V	
140		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
141	ZD2	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
142		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	0.05	5V →1.8V	
143	ZD4	S/C	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	
144		OPEN	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes [有] <input checked="" type="checkbox"/> No [無]	None	None	

Compliance [判定] : Yes [合] / No [否]