



ABNORMAL TEST RESULT

OF MODEL LFP100F

1. Did Cheese Cloth or Paper Glow?

No.

2. Did Ground Fuse Open?

No.

3. Dielectric breakdown?

No.

4. Other Results?

See the following pages .

(FMEA : 2/17 ~ 16/17)
(Abnormal Test Result: 17/17 ~ 17/17)

There was no emission of flame, molten metal, ignition of cheesecloth, dielectric breakdown, opening of the ground fuse, other indication of a shock or fire hazard.

F M E A

Component	Mode	Comment	Output Voltage (V)
C101	Open	Normal operation.	AVR1:*
	Short	F101 opened, No hazard.	AVR1:0
C102	Open	Normal operation.	AVR1:*
	Short	F101 opened, No hazard.	AVR1:0
C103	Open	Normal operation.	AVR1:*
	Short	F101 opened, No hazard.	AVR1:0
C110	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C111	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C113	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C114	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C115	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C116	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C117	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C118	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C119	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
C120	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C121	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C122	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C123	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C124	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C127	Open	No Hazard.	AVR1:0
	Short	No Hazard.	AVR1:0
C131	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C201	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
C202	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
C203	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C204	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C205	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
C206	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C207	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
C211	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C212	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
C216	Open	Normal operation.	AVR1:*
	Short	See 17 Page.	
C217	Open	Normal operation.	AVR1:*
	Short	See 17 Page.	
C221	Open	Normal operation.	AVR1:*
	Short	Output voltage decreased. No hazard.	AVR1:decreased
C501	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C502	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
C503	Open	Normal operation.	AVR1:*
	Short	See 17 Page.	
C504	Open	Normal operation.	AVR1:*
	Short	See 17 Page.	
C505	Open	only 24	Normal operation.
	Short	only 24	Normal operation.

F M E A

Component	Mode		Comment	Output Voltage (V)
C506	Open	only 24	Normal operation.	AVR1:*
	Short	only 24	Normal operation.	AVR1:*
C512	Open		Normal operation.	AVR1:*
	Short		Output voltage decreased. No hazard.	AVR1:decreased
C513	Open		Normal operation.	AVR1:*
	Short		Output voltage decreased. No hazard.	AVR1:decreased
C602	Open		Output voltage decreased. No hazard.	AVR1:decreased
	Short		Output voltage decreased. No hazard.	AVR1:decreased
C603	Open		Output voltage decreased. No hazard.	AVR1:decreased
	Short		Output voltage decreased. No hazard.	AVR1:decreased
D101	Open		Output voltage decreased. No hazard.	AVR1:decreased
	Short		No Hazard.	AVR1:0
D103	Open		Normal operation.	AVR1:*
	Short		Normal operation.	AVR1:*
D104	Open		Normal operation.	AVR1:*
	Short		Normal operation.	AVR1:*
D105	Open		Normal operation.	AVR1:*
	Short		Normal operation.	AVR1:*
D106	Open		Normal operation.	AVR1:*
	Short		Normal operation.	AVR1:*
D107	Open		Normal operation.	AVR1:*
	Short		Normal operation.	AVR1:*
D108	Open		Normal operation.	AVR1:*
	Short		Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
D109	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
D111	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
D112	Open	No Hazard.	AVR1:0
	Short	Normal operation.	AVR1:*
D201	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
D202	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
D203	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
D204	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
D205	Open	Normal operation.	AVR1:*
	Short	No Hazard.	AVR1:0
D206	Open	Normal operation.	AVR1:*
	Short	Normal operation.	AVR1:*
D211	Open	No Hazard.	AVR1:0
	Short	Normal operation.	AVR1:*
IC101	Open	1	No Hazard.
		2	Normal operation.
		3	Normal operation.
		4	No Hazard.

F M E A

Component	Mode		Comment	Output Voltage (V)
IC101	Open	5	Normal operation.	AVR1:*
		6	No Hazard.	AVR1:*
		7	No Hazard.	AVR1:*
		8	No Hazard.	AVR1:*
	Short	1-2	Normal operation.	AVR1:*
		2-3	No Hazard.	AVR1:0
		3-4	No Hazard.	AVR1:0
		5-6	No Hazard.	AVR1:0
		6-7	No Hazard.	AVR1:0
		7-8	No Hazard.	AVR1:0
IC201	Open	1	No Hazard.	AVR1:0
		2	No Hazard.	AVR1:0
		3	Normal operation.	AVR1:*
		4	No Hazard.	AVR1:0
		5	No Hazard.	AVR1:0
		6	No Hazard.	AVR1:0
		7	Normal operation.	AVR1:*
		8	No Hazard.	AVR1:0
	Short	1-2	No Hazard.	AVR1:0
		2-3	No Hazard.	AVR1:0
		3-4	Normal operation.	AVR1:*
		5-6	No Hazard.	AVR1:0
		6-7	Normal operation.	AVR1:*
		7-8	Normal operation.	AVR1:*

F M E A

Component	Mode		Comment	Output Voltage (V)
IC601	Open	K	No Hazard.	AVR1:0
		A	No Hazard.	AVR1:0
		R	No Hazard.	AVR1:0
	Short	A-K	Output voltage decreased. No hazard.	AVR1:decreased
		K-R	Output voltage decreased. No hazard.	AVR1:decreased
		R-A	No Hazard.	AVR1:0
J601	Open	only 24	No Hazard.	AVR1:0
L101	Open		No Hazard.	AVR1:0
	Short		Normal operation.	AVR1:*
L102	Open		No Hazard.	AVR1:0
	Short		Normal operation.	AVR1:*
L104	Open	1	Normal operation.	AVR1:*
		5	No Hazard.	AVR1:0
		6	No Hazard.	AVR1:0
		9	Normal operation.	AVR1:*
L507	Open		F101 opened, No hazard.	AVR1:0
	Short		Output voltage decreased. No hazard.	AVR1:decreased
PC201	Open	A, K	No Hazard.	AVR1:0
		C, E	No Hazard.	AVR1:0
	Short	A-K	No Hazard.	AVR1:0
		C-E	No Hazard.	AVR1:0
PC202	Open	A, K	Normal operation.	AVR1:*
		C, E	Normal operation.	AVR1:*
	Short	A-K	Normal operation.	AVR1:*

F M E A

Component	Mode		Comment	Output Voltage (V)
PC202	Short	C-E	No Hazard.	AVR1:0
PTH201	Open		No Hazard.	AVR1:0
	Short		No Hazard.	AVR1:0
SS101	Open		No Hazard.	AVR1:0
	Short		No Hazard.	AVR1:0
SS501	Open	Cathode	No Hazard.	AVR1:0
		Alternative	See 17 Page.	
SS502	Open	Cathode	No Hazard.	AVR1:0
		Alternative	See 17 Page.	
T201	Open	2	No Hazard.	AVR1:0
		3	Normal operation.	AVR1:*
		4	Normal operation.	AVR1:*
		5	Normal operation.	AVR1:*
		6	No Hazard.	AVR1:0
		9	Normal operation.	AVR1:*
		10	Normal operation.	AVR1:*
		11	Normal operation.	AVR1:*
		12	Normal operation.	AVR1:*
		2-3	F101 opened, No hazard.	AVR1:0
	Short	3-4	No Hazard.	AVR1:0
		4-5	Normal operation.	AVR1:*
		5-6	F101 opened, No hazard.	AVR1:0
	9, 10-11, 12		No Hazard.	AVR1:0
TH101	Open		No Hazard.	AVR1:0

F M E A

Component	Mode		Comment	Output Voltage (V)
TH101	Short		Normal operation.	AVR1:*
TR101	Open	D	See 17 Page.	
		S	See 17 Page.	
		G	See 17 Page.	
	Short	D-S	See 17 Page.	
		S-G	See 17 Page.	
		G-D	See 17 Page.	
TR103	Open	D	Normal operation.	AVR1:*
		S	Normal operation.	AVR1:*
		G	Normal operation.	AVR1:*
	Short	D-S	No Hazard.	AVR1:0
		S-G	Normal operation.	AVR1:*
		G-D	No Hazard.	AVR1:0
TR104	Open	D	Normal operation.	AVR1:*
		S	Normal operation.	AVR1:*
		G	Normal operation.	AVR1:*
	Short	D-S	Normal operation.	AVR1:*
		S-G	Normal operation.	AVR1:*
		G-D	Normal operation.	AVR1:*
TR105	Open	C	Normal operation.	AVR1:*
		E	Normal operation.	AVR1:*
		B	Normal operation.	AVR1:*
	Short	C-E	Normal operation.	AVR1:*
		E-B	Normal operation.	AVR1:*

F M E A

Component	Mode		Comment	Output Voltage (V)
TR105	Short	B-C	Normal operation.	AVR1:*
TR109	Open	C	Normal operation.	AVR1:*
		E	Normal operation.	AVR1:*
		B	Normal operation.	AVR1:*
	Short	C-E	No Hazard.	AVR1:0
		E-B	Normal operation.	AVR1:*
		B-C	No Hazard.	AVR1:0
TR201	Open	D	See 17 Page.	
		S	See 17 Page.	
		G	See 17 Page.	
	Short	D-S	See 17 Page.	
		S-G	See 17 Page.	
		G-D	See 17 Page.	
TR204	Open	C	Normal operation.	AVR1:*
		E	Normal operation.	AVR1:*
		B	Normal operation.	AVR1:*
	Short	C-E	No Hazard.	AVR1:0
		E-B	No Hazard.	AVR1:0
		B-C	No Hazard.	AVR1:0
VR601	Open	brush	Output voltage decreased. No hazard.	AVR1:decreased
			No Hazard.	AVR1:0
	Short		No Hazard.	AVR1:0
ZD101	Open		Normal operation.	AVR1:*
	Short		Normal operation.	AVR1:*

F M E A

Component	Mode		Comment	Output Voltage (V)
ZD102	Open		Normal operation.	AVR1:*
	Short		Normal operation.	AVR1:*
ZD104	Open		Normal operation.	AVR1:*
	Short		Normal operation.	AVR1:*
ZD105	Open		Normal operation.	AVR1:*
	Short		Normal operation.	AVR1:*
ZD202	Open		Normal operation.	AVR1:*
	Short		No Hazard.	AVR1:0
ZD501	Open		Normal operation.	AVR1:*
	Short		No Hazard.	AVR1:0
ZD502	Open		Normal operation.	AVR1:*
	Short		No Hazard.	AVR1:0
ZD601	Open	except 24	No Hazard.	AVR1:0
	Short	except 24	No Hazard.	AVR1:0
R101	Open		Normal operation.	AVR1:*
R102	Open		Normal operation.	AVR1:*
R103	Open		Normal operation.	AVR1:*
R104	Open		Normal operation.	AVR1:*
R105	Open		Normal operation.	AVR1:*
R118	Open		Normal operation.	AVR1:*
R119	Open		Normal operation.	AVR1:*
R120	Open		Normal operation.	AVR1:*
R121	Open		Normal operation.	AVR1:*
R122	Open		Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
R123	Open	Normal operation.	AVR1:*
R124	Open	Normal operation.	AVR1:*
R125	Open	Normal operation.	AVR1:*
R126	Open	Normal operation.	AVR1:*
R127	Open	Normal operation.	AVR1:*
R128	Open	Normal operation.	AVR1:*
R129	Open	Normal operation.	AVR1:*
R130	Open	Normal operation.	AVR1:*
R131	Open	No Hazard.	AVR1:0
R132	Open	Normal operation.	AVR1:*
R133	Open	Normal operation.	AVR1:*
R134	Open	Normal operation.	AVR1:*
R135	Open	Normal operation.	AVR1:*
R136	Open	Normal operation.	AVR1:*
R137	Open	Normal operation.	AVR1:*
R143	Open	No Hazard.	AVR1:0
R146	Open	Normal operation.	AVR1:*
R148	Open	Normal operation.	AVR1:*
R149	Open	Normal operation.	AVR1:*
R150	Open	Normal operation.	AVR1:*
R151	Open	Normal operation.	AVR1:*
R152	Open	No Hazard.	AVR1:0
R153	Open	No Hazard.	AVR1:0
R155	Open	No Hazard.	AVR1:0

F M E A

Component	Mode	Comment	Output Voltage (V)
R156	Open	No Hazard.	AVR1:0
R157	Open	No Hazard.	AVR1:0
R158	Open	No Hazard.	AVR1:0
R159	Open	No Hazard.	AVR1:0
R160	Open	No Hazard.	AVR1:0
R161	Open	No Hazard.	AVR1:0
R162	Open	No Hazard.	AVR1:0
R164	Open	Normal operation.	AVR1:*
R165	Open	Normal operation.	AVR1:*
R201	Open	Normal operation.	AVR1:*
R202	Open	Normal operation.	AVR1:*
R203	Open	Normal operation.	AVR1:*
R204	Open	Normal operation.	AVR1:*
R205	Open	Normal operation.	AVR1:*
R206	Open	Normal operation.	AVR1:*
R207	Open	Normal operation.	AVR1:*
R208	Open	Normal operation.	AVR1:*
R211	Open	Normal operation.	AVR1:*
R212	Open	Normal operation.	AVR1:*
R213	Open	Normal operation.	AVR1:*
R216	Open	No Hazard.	AVR1:0
R217	Open	No Hazard.	AVR1:0
R221	Open	Normal operation.	AVR1:*
R222	Open	Normal operation.	AVR1:*

F M E A

Component	Mode	Comment	Output Voltage (V)
R226	Open	Normal operation.	AVR1:*
R227	Open	Normal operation.	AVR1:*
R229	Open	No Hazard.	AVR1:0
R230	Open	No Hazard.	AVR1:0
R231	Open	No Hazard.	AVR1:0
R233	Open	Normal operation.	AVR1:*
R234	Open	Normal operation.	AVR1:*
R236	Open	Output voltage decreased. No hazard.	AVR1:decreased
R237	Open	Output voltage decreased. No hazard.	AVR1:decreased
R255	Open	Normal operation.	AVR1:*
R281	Open	Normal operation.	AVR1:*
R501	Open	Normal operation.	AVR1:*
R502	Open	Normal operation.	AVR1:*
R503	Open	Normal operation.	AVR1:*
R504	Open	Normal operation.	AVR1:*
R505	Open	Normal operation.	AVR1:*
R506	Open	Normal operation.	AVR1:*
R511	Open	Normal operation.	AVR1:*
R512	Open	Normal operation.	AVR1:*
R513	Open	Normal operation.	AVR1:*
R514	Open	Normal operation.	AVR1:*
R515	Open	Normal operation.	AVR1:*
R516	Open	Normal operation.	AVR1:*
R517	Open	Normal operation.	AVR1:*

F M E A

Component	Mode		Comment	Output Voltage (V)
R518	Open		Normal operation.	AVR1:*
R519	Open		Normal operation.	AVR1:*
R520	Open		Normal operation.	AVR1:*
R551	Open		Normal operation.	AVR1:*
R552	Open		Normal operation.	AVR1:*
R553	Open		Normal operation.	AVR1:*
R554	Open		Normal operation.	AVR1:*
R555	Open		Normal operation.	AVR1:*
R556	Open		Normal operation.	AVR1:*
R557	Open		Normal operation.	AVR1:*
R558	Open		Normal operation.	AVR1:*
R559	Open		Normal operation.	AVR1:*
R560	Open	except 24	Normal operation.	AVR1:*
R561	Open	except 24	Normal operation.	AVR1:*
R562	Open	except 24	Normal operation.	AVR1:*
R601	Open		Output voltage decreased. No hazard.	AVR1:decreased
R602	Open		Output voltage decreased. No hazard.	AVR1:decreased
R603	Open		Normal operation.	AVR1:*
R604	Open		Output voltage decreased. No hazard.	AVR1:decreased
R605	Open		No Hazard.	AVR1:0
R606	Open		No Hazard.	AVR1:0
R607	Open		Output voltage decreased. No hazard.	AVR1:decreased
R609	Open		Output voltage decreased. No hazard.	AVR1:decreased

ABNORMAL TEST RESULT

Component	Mode		Comment	Output Voltage (V)
C216	Short		Normal operation.	AVR1:*
C217	Short		Normal operation.	AVR1:*
C503	Short		Normal operation.	AVR1:*
C504	Short		Normal operation.	AVR1:*
SS501	Open	Alternative	Normal operation.	AVR1:*
SS502	Open	Alternative	Normal operation.	AVR1:*
TR101	Open	D	No Hazard.	AVR1:0
		S	No Hazard.	AVR1:0
		G	No Hazard.	AVR1:0
	Short	D-S	No Hazard.	AVR1:0
		S-G	No Hazard.	AVR1:0
		G-D	No Hazard.	AVR1:0
TR201	Open	D	No Hazard.	AVR1:0
		S	No Hazard.	AVR1:0
		G	No Hazard.	AVR1:0
	Short	D-S	No Hazard.	AVR1:0
		S-G	No Hazard.	AVR1:0
		G-D	No Hazard.	AVR1:0