

## YAS-YAW series Recommended Models for Replacements

(Please check detail specifications in the catalog.)

### YAS5

No.	Discontinued Models						Recommended Models for Replacement					
	Model	Input Voltage [V]	No.	Output Voltage [V]	Output Current [A]	Remarks	Model	Input Voltage [V]	No.	Output Voltage [V]	Output Current [A]	Remarks
1	YAS505	AC85-264	-	5	1.0		TUHS5F05	AC85-264	-	5	1.0	
2	YAS512		-	12	0.45		TUHS5F12		-	12	0.45	

\*1 To use TUHS, external components are required. Refer to the instruction manual for details.

### YAS10

No.	Discontinued Models						Recommended Models for Replacement					
	Model	Input Voltage [V]	No.	Output Voltage [V]	Output Current [A]	Remarks	Model	Input Voltage [V]	No.	Output Voltage [V]	Output Current [A]	Remarks
1	YAS1005	AC85-264	-	5	2.0		TUHS10F05	AC85-264	-	5	2.0	
2	YAS1012		-	12	0.9		TUHS10F12		-	12	0.9	

\*1 To use TUHS, external components are required. Refer to the instruction manual for details.

### YAW5

No.	Discontinued Models						Recommended Models for Replacement					
	Model	Input Voltage [V]	No.	Output Voltage [V]	Output Current [A]	Remarks	Model *1	Input Voltage [V]	No.	Output Voltage [V]	Output Current [A]	Remarks
1	YAW512	AC85-264	V1	12	0.22	+/-12V output. Non-isolation between V1 and V2	TUHS3F12 x 2	AC85-264	V1	12	0.25	Two units of power supplies should be used .
			V2	12	0.22				V2	12	0.25	
2	YAW512		-	24	0.22	TUHS5F24	-		24	0.22		
3	YAW515		V1	15	0.17	+/-15V output. Non-isolation between V1 and V2	TUHS3F15 x 2		V1	15	0.2	Two units of power supplies should be used .
			V2	15	0.17				V2	15	0.2	
4	YAW515		-	30	0.17		TUHS3F15 x 2		-	30	0.2	Two units of power supplies should be used .

\*1 To use TUHS, external components are required. Refer to the instruction manual for details.

### YAW10

No.	Discontinued Models						Recommended Models for Replacement					
	Model	Input Voltage [V]	No.	Output Voltage [V]	Output Current [A]	Remarks	Model *1	Input Voltage [V]	No.	Output Voltage [V]	Output Current [A]	Remarks
1	YAW1012	AC85-264	V1	12	0.45	+/-12V output. Non-isolation between V1 and V2	TUHS5F12 x 2	AC85-264	V1	12	0.45	Two units of power supplies should be used .
			V2	12	0.45				V2	12	0.45	
2	YAW1012		-	24	0.45	TUHS15F24	-		24	0.63		
3	YAW1015		V1	15	0.35	+/-15V output. Non-isolation between V1 and V2	TUHS5F15 x 2		V1	15	0.34	Two units of power supplies should be used .
			V2	15	0.35				V2	15	0.34	
4	YAW1015		-	30	0.35		TUHS5F15 x 2		-	30	0.34	Two units of power supplies should be used .

\*1 To use TUHS, external components are required. Refer to the instruction manual for details.