

Model	TUHS3F05	Temperature Testing Circuitry	25°C Figure A																								
Item	Switching Frequency																										
Object _____																											
1.Graph			2.Values																								
Input Voltage : AC100V																											
<table border="1"> <thead> <tr> <th>Load Current [A]</th> <th>Switching Frequency [kHz]</th> </tr> </thead> <tbody> <tr><td>0.00</td><td>217</td></tr> <tr><td>0.06</td><td>192</td></tr> <tr><td>0.12</td><td>176</td></tr> <tr><td>0.18</td><td>160</td></tr> <tr><td>0.24</td><td>158</td></tr> <tr><td>0.30</td><td>150</td></tr> <tr><td>0.36</td><td>138</td></tr> <tr><td>0.42</td><td>133</td></tr> <tr><td>0.48</td><td>122</td></tr> <tr><td>0.54</td><td>118</td></tr> <tr><td>0.60</td><td>111</td></tr> </tbody> </table>			Load Current [A]	Switching Frequency [kHz]	0.00	217	0.06	192	0.12	176	0.18	160	0.24	158	0.30	150	0.36	138	0.42	133	0.48	122	0.54	118	0.60	111	
Load Current [A]	Switching Frequency [kHz]																										
0.00	217																										
0.06	192																										
0.12	176																										
0.18	160																										
0.24	158																										
0.30	150																										
0.36	138																										
0.42	133																										
0.48	122																										
0.54	118																										
0.60	111																										
Input Voltage : AC200V																											
<table border="1"> <thead> <tr> <th>Load Current [A]</th> <th>Switching Frequency [kHz]</th> </tr> </thead> <tbody> <tr><td>0.00</td><td>215</td></tr> <tr><td>0.06</td><td>217</td></tr> <tr><td>0.12</td><td>211</td></tr> <tr><td>0.18</td><td>196</td></tr> <tr><td>0.24</td><td>191</td></tr> <tr><td>0.30</td><td>181</td></tr> <tr><td>0.36</td><td>172</td></tr> <tr><td>0.42</td><td>161</td></tr> <tr><td>0.48</td><td>161</td></tr> <tr><td>0.54</td><td>148</td></tr> <tr><td>0.60</td><td>142</td></tr> </tbody> </table>			Load Current [A]	Switching Frequency [kHz]	0.00	215	0.06	217	0.12	211	0.18	196	0.24	191	0.30	181	0.36	172	0.42	161	0.48	161	0.54	148	0.60	142	
Load Current [A]	Switching Frequency [kHz]																										
0.00	215																										
0.06	217																										
0.12	211																										
0.18	196																										
0.24	191																										
0.30	181																										
0.36	172																										
0.42	161																										
0.48	161																										
0.54	148																										
0.60	142																										

-Switching frequency of TUHS changes depending on load current and input voltage.

-When load current is low, TUHS operates intermittently, so switching frequency would not become constant.