

Model	TUHS3F12	Temperature Testing Circuitry	25°C Figure A																								
Item	Switching Frequency																										
Object _____																											
1.Graph			2.Values																								
Input Voltage : AC100V																											
<table border="1"> <thead> <tr> <th>Load Current [A]</th> <th>Switching Frequency [kHz]</th> </tr> </thead> <tbody> <tr><td>0.00</td><td>201</td></tr> <tr><td>0.03</td><td>191</td></tr> <tr><td>0.05</td><td>181</td></tr> <tr><td>0.08</td><td>172</td></tr> <tr><td>0.10</td><td>161</td></tr> <tr><td>0.13</td><td>155</td></tr> <tr><td>0.15</td><td>152</td></tr> <tr><td>0.18</td><td>142</td></tr> <tr><td>0.20</td><td>132</td></tr> <tr><td>0.23</td><td>130</td></tr> <tr><td>0.25</td><td>125</td></tr> </tbody> </table>			Load Current [A]	Switching Frequency [kHz]	0.00	201	0.03	191	0.05	181	0.08	172	0.10	161	0.13	155	0.15	152	0.18	142	0.20	132	0.23	130	0.25	125	
Load Current [A]	Switching Frequency [kHz]																										
0.00	201																										
0.03	191																										
0.05	181																										
0.08	172																										
0.10	161																										
0.13	155																										
0.15	152																										
0.18	142																										
0.20	132																										
0.23	130																										
0.25	125																										
Input Voltage : AC200V																											
<table border="1"> <thead> <tr> <th>Load Current [A]</th> <th>Switching Frequency [kHz]</th> </tr> </thead> <tbody> <tr><td>0.00</td><td>223</td></tr> <tr><td>0.03</td><td>223</td></tr> <tr><td>0.05</td><td>220</td></tr> <tr><td>0.08</td><td>203</td></tr> <tr><td>0.10</td><td>202</td></tr> <tr><td>0.13</td><td>192</td></tr> <tr><td>0.15</td><td>186</td></tr> <tr><td>0.18</td><td>176</td></tr> <tr><td>0.20</td><td>169</td></tr> <tr><td>0.23</td><td>163</td></tr> <tr><td>0.25</td><td>162</td></tr> </tbody> </table>			Load Current [A]	Switching Frequency [kHz]	0.00	223	0.03	223	0.05	220	0.08	203	0.10	202	0.13	192	0.15	186	0.18	176	0.20	169	0.23	163	0.25	162	
Load Current [A]	Switching Frequency [kHz]																										
0.00	223																										
0.03	223																										
0.05	220																										
0.08	203																										
0.10	202																										
0.13	192																										
0.15	186																										
0.18	176																										
0.20	169																										
0.23	163																										
0.25	162																										

-Switching frequency of TUHS changes depending on load current and input voltage.

-When load current is low, TUHS operates intermittently, so switching frequency would not become constant.